



www.rosefix.com

www.vinafix.vn

PDF PAGE	CSA PAGE	CONTENTS	SYNC MASTER	DATE
2	2	H6P JTAG,USB,PLL,HSIC,XTAL	N/A	N/A
3	3	H6P DIGITAL I/O,BOOTSTRAPPING	N/A	N/A
4	4	H6P VDDCA,VDD1/2,VDD,VDD_CPU,VDD_GPU	N/A	N/A
5	5	H6P GND,VDDIO18,VDDIOD,VDD_SRAM,VDD_SOC	N/A	N/A
6	6	H6P NAND,NAND 12X17	N/A	N/A
7	7	H6P HIGH SPEED DIG (CAM,LCM,DP)	N/A	N/A
8	8	BUTTON FLEX B2B	N/A	N/A
9	9	L67 AUDIO CODEC (1/2)	N/A	N/A
10	10	L67 AUDIO CODEC (2/2)	N/A	N/A
11	11	FRONT CAM FLEX B2B	N/A	N/A
12	12	AMBER PMU(1/2)	N/A	N/A
13	13	AMBER PMU(2/2)	N/A	N/A
14	14	CHESTNUT,BACKLIGHT DRIVER,MESA BOOST	N/A	N/A
15	15	SPKR AMP + STROBE DRIVER	N/A	N/A
16	16	TRISTAR,EEPROM	N/A	N/A
17	17	DOCKFLEX B2B	N/A	N/A
18	18	D403 (TOUCH B2B, DRIVER ICS)	N/A	N/A
19	19	LCM B2B	N/A	N/A
20	20	OSCAR + SENSORS	N/A	N/A
21	21	REAR CAM B2B	N/A	N/A
22	22	BATT B2B, TPS, PD FEATURES	N/A	N/A
23	23	VOLTAGE PROPERTIES		
24	24	RADIO_MLB HIERARCH. SYMBOL	N/A	N/A
25	25	Cross Reference Page		
26	26	Cross Reference Page		
27	27	Cross Reference Page		

SCH 051-9681
BRD 820-3382
MCO 056-5179
BOM 639-4159 (16GB) X152
BOM 639-4160 (32GB) X152
BOM 639-3973 (64GB) X152

COMPASS BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
639-4269	1	COMPASS INTERPOSER X152/X145	U16	Y	COMPASS_INTERPOSER

HORIZONTAL AND OTHER CAP BOM OPTIONS

	PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
PP_VCC_MAIN BULK CAP (AP)	138S0801	5	HRZNTL CAPS_1: 10UF,0402,6.3V	C422,C399,C405,C417,C418	Y	HRZNTL_CAP_GRP1
	138S0801	5	HRZNTL CAPS_2: 10UF,0402,6.3V	C250,C251,C325,C357,C358	Y	HRZNTL_CAP_GRP2
	138S0801	5	HRZNTL CAPS_3: 10UF,0402,6.3V	C260,C263,C267,C270,C261	Y	HRZNTL_CAP_GRP3
	138S0801	4	HRZNTL CAPS_4: 10UF,0402,6.3V	C264,C268,C271,C385	Y	HRZNTL_CAP_GRP4
	138S0801	4	HRZNTL CAPS_5: 10UF,0402,6.3V	C398,C411,C252,C297	Y	HRZNTL_CAP_GRP5
PP_BATT_VCC BULK CAP (AP)	138S0801	5	HRZNTL CAPS_6: 10UF,0402,6.3V	C386,C387,C333,C332,C335	Y	HRZNTL_CAP_GRP6
PP_BATT_VCC BULK CAP (RF)	138S0801	3	HRZNTL CAPS_7: 10UF,0402,6.3V	C42_RF,C43_RF,C44_RF	Y	HRZNTL_CAP_GRP7
	138S0801	1	HRZNTL CAPS_8: 10UF,0402,6.3V	C1201_RF	Y	HRZNTL_CAP_GRP8
PP_VCC_MAIN BULK CAP (RF)	138S0801	1	HRZNTL CAPS_9: 10UF,0402,6.3V	C103_RF	Y	HRZNTL_CAP_GRP9
PP3V0_NAND BULK CAP	138S0801	4	HRZNTL CAPS_10: 10UF,0402,6.3V	C182,C307,C209,C187	Y	HRZNTL_CAP_GRP10
PP5V7_SAGE_AVDDH BULK CAP	138S0794	2	HRZNTL CAPS_11: 10UF,0402,10V	C52,C156	Y	HRZNTL_CAP_GRP11

INDUCTOR BOM OPTIONS

	PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
BUCK0 SLAVE	152S1785	3	BUCK0 SLAVE IND: 0.47UH, TFA-A TDK	L10,L12,L14	Y	IND_BUCK0_SLV_P47UH_TFA-A_TDK
	152S1834	3	BUCK0 SLAVE IND: 0.47UH, CYNTEC	L10,L12,L14	Y	IND_BUCK0_SLV_P47UH_CYNTEC
	152S1839	3	BUCK0 SLAVE IND: 0.47UH, TAIYO	L10,L12,L14	Y	IND_BUCK0_SLV_P47UH_TAIYO
BUCKXX MASTER	152S1807	6	AMBER BUCKXX IND: 1UH TFA-A TDK	L9,L11,L13,L15,L16,L17	Y	IND_BUCKXX_1UH_TFA-A_TDK
	152S1801	6	AMBER BUCKXX IND: 1UH CYNTEC	L9,L11,L13,L15,L16,L17	Y	IND_BUCKXX_1UH_CYNTEC
	152S1840	6	AMBER BUCKXX IND: 1UH TAIYO	L9,L11,L13,L15,L16,L17	Y	IND_BUCKXX_1UH_TAIYO
STROBE	152S1807	1	STROBE IND: 1UH TFA-A TDK	L5	Y	IND_STROBE_1UH_TFA-A_TDK
	152S1801	1	STROBE IND: 1UH CYNTEC	L5	Y	IND_STROBE_1UH_CYNTEC
	152S1840	1	STROBE IND: 1UH TAIYO	L5	Y	IND_STROBE_1UH_TAIYO
BUCK5	152S1809	1	BUCK5 2012 IND: 1UH TFA-A TDK	L18	Y	IND_BUCK5_1UH_TFA-A_TDK
	152S1835	1	BUCK5 2012 IND: 1UH CYNTEC	L18	Y	IND_BUCK5_1UH_CYNTEC
	152S1843	1	BUCK5 2012 IND: 1UH TAIYO	L18	Y	IND_BUCK5_1UH_TAYIO
SPKR AMP	152S1836	1	SPKR AMP IND: 1.2UH CYNTEC	L4	Y	IND_SPKRAMP_1P2UH_CYNTEC
	152S1844	1	SPKR AMP IND: 1.2UH TAIYO	L4	Y	IND_SPKAMP_1P2UH_TAIYO
CHARGER	152S1721	1	CHARGER IND: 2.2UH TAIYO	L8	Y	IND_CHGR_2P2UH_TAIYO

FOR CHESTNUT BOMTABLE - SEE PG 14
FOR RADIO BOMTABLE - SEE PG 24
FOR MISC R/L/C ALTS - SEE PG 2

I2C ADDRESS MAP

I2C0

DEVICE	BINARY	7-BIT HEX	8-BIT HEX
AMBER PMU:	1110100X	0X74	0XE8
CS35L19B AMP:	1000000X	0X40	0X80
LM3534 BL DRIVER:	1100011X	0X63	0XC6
TRISTAR:	0011010X	0X1A	0X34
CHESTNUT:	0100111X	0X27	0X4E

I2C1

CT814 ALS:	0101001X	0X29	0X52

RCAM I2C

OPEL STROBE DRIVER:	1100011X	0X63	0XC6
REAR FACING CAM:	0010000X	0X10	0X20
ADI VCM AF DRIVER:	0001110X	0X0E	0X1C
ROHM VCM AF DRIVER:	0001100X	0X0C	0X18

FCAM I2C

FRONT FACING CAM:	0110110X	0X36	0X6C

NOTE: ACCEL, GYRO, COMPASS ALL USING SPI (VIA OSCAR) FOR AP COMMUNICATION.

X152 BOM CALLOUTS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
051-9681	1	SCH, SINGLE_BRD, X152	SCH	Y	?
820-3382	1	PCBF, SINGLE_BRD, X152	PCB	Y	?
825-6838	1	EEEE FOR 639-4159 16GB	EEEE_F7V1	Y	EEEE_16G
825-6838	1	EEEE FOR 639-4160 32GB	EEEE_F7V2	Y	EEEE_32G
825-6838	1	EEEE FOR 639-3973 64GB	EEEE_F4LR	Y	EEEE_64G
339S0206	1	H6P + 1GB SAMSUNG	U1	Y	H6P_1GB_SAMSUNG
339S0207	1	H6P + 1GB ELPIDA	U1	Y	H6P_1GB_ELPIDA
339S0208	1	H6P + 1GB HYNIX	U1	Y	H6P_1GB_HYNIX

OSCAR BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
337S4370	1	OSCAR CSP	U9	Y	OSCAR_CSP
337S4417	1	OSCAR FCLGA	U9	Y	OSCAR_FCLGA

OPEL BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
353S3899	1	TI OPEL	U17	Y	OPEL_TI

NAND BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
335S0930	1	NAND,19NM,16GX8,MLC,PPN1.5	U4	Y	NAND_16G_HYNIX
335S0931	1	NAND,19NM,32GX8,MLC,PPN1.5	U4	Y	NAND_32G_HYNIX
335S0932	1	NAND,19NM,64GX8,MLC,PPN1.5	U4	Y	NAND_64G_HYNIX

NAND BOM ALTERNATES

PART NUMBER	ALTERNATE FOR PART NUMBER	BOM OPTION	REF DES	COMMENTS:
335S0921	335S0930	NAND_16G_TOSH	U4	?
335S0933	335S0930	NAND_16G_SAND	U4	?
335S0922	335S0931	NAND_32G_TOSH	U4	?
335S0934	335S0931	NAND_32G_SAND	U4	?
335S0923	335S0932	NAND_64G_TOSH	U4	?
335S0935	335S0932	NAND_64G_SAND	U4	?

USB GOLDENEYE BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
155S0583	2	E75 COMMON MODE CHOKES	L20,L22	Y	CMC_E75_DIFFPAIRS
152S1737	2	USB TX 10UH SERIES INDUCTORS	R163,R164	Y	USB_TX_SERIES_IND

TRISTAR BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
343S0614	1	CBTL1608A1UK,WCSP,TRISTAR	U2	Y	TRISTAR
343S0639	1	CBTL1610A0UK,WCSP.TRISTAR2	U2	Y	TRISTAR2
117S0202	2	RES 20OHM 01005 5%, TRISTAR2	R102,R103	Y	TRISTAR2
118S0671	2	RES 15OHM 01005 5%, TRISTAR	R102,R103	Y	TRISTAR

AUDIO BOM OPTION

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
155S0556	2	FERRITE 0402 P14OHM 1A	FL6, FL9	Y	SPKAMP_FERRITE_REG
155S0731	2	FERRITE 0402 P06OHM 1P8A	FL6, FL9	Y	SPKAMP_FERRITE_LOWDCR
116S0004	2	RESISTOR 0402 0OHM 1A	FL6, FL9	Y	SPKAMP_FERRITE_0OHM
132S0396	2	CAP 01005 10V 1000PF	C500, C501	Y	SPKAMP_CAPFILT_1000PF
132S0437	2	CAP 01005 10V 150PF	C500, C501	Y	SPKAMP_CAPFILT_150PF
131S0283	2	CAP 01005 10V 100PF	DZ13, DZ14	Y	SPKAMP_ESDFILT_100PF
338S1077	1	CLASSD AMP, L19	U22	Y	SPKAMP_IC_L19
338S1161	1	CLASSD AMP, L20	U22	Y	SPKAMP_IC_L20
117S0002	1	0201 0OHM	R128	Y	SPKAMP_SENSE_R_L20
118S0583	1	0201 0.1OHM	R128	Y	SPKAMP_SENSE_R_L19

www.vinafix.vn

H6P: JTAG, USB, PLL, HSIC, XTAL

MISC COMPONENTS ALTERNATES

PART NUMBER	ALTERNATE FOR PART NUMBER	BOM OPTION	REF DES	COMMENTS:
107S0146	107S0208			ALT FOR THERMISTOR
138S0702	138S0657			?
138S0697	138S0695			?
138S0746	138S0705			?
138S0739	138S0706			?
155S0773	155S0453			?
155S0667	155S0583			?
335S0895	335S0874			?
138S0703	138S0648			?



www.vinafix.vn

H6P: DIGITAL I/O, BOOTSTRAPPING



BOOTSTRAPPING (BOARD_REV, BOARD_ID, BOOT_CFG)

BOARD_REV[3:0]={GPIO34, GPIO35, GPIO36, GPIO37}
FLOAT=LOW, PULLUP=HIGH

1111	PROTO2/2A, TRISAR/L19	
1110	PROTO2A, TRISTAR2/L20	
1101	EVT1 MAIN BUILD	<--- SELECTED
1100	EVT1 MESA BUILD	<--- DNP R3000 TO SELECT

BOARD_ID[3:0]={GPIO16, SPIO0_MISO, SPI0_MOSI, SPI0_SCLK}
FLOAT=LOW, PULLUP=HIGH

0000	X145 MLB	
0001	X145 DEV	
0010	X152 MLB	<--- SELECTED
0011	X152 DEV	

BOOT_CONFIG[3:0]={GPIO29_CONFIG3,GPIO28_CONFIG2,GPIO25_CONFIG1,GPIO18_CONFIG0}
FLOAT=LOW, PULLUP=HIGH

0000	SPI0
0001	SPI0 TEST MODE
0010	NAND
0011	NAND TEST MODE <--- SELECTED

COMMON PULL UP FOR BOARD_REV, BOARD_ID AND BOOT_CONFIG PINS



MENU & POWER / HOLD KEY BUFFER

PCB: PLACE THIS TOP SIDE, NORTH END OF SINGLE_BRD



PCB: PLACE THIS BOTTOM SIDE, SOUTH END OF SINGLE_BRD



www.vinafix.vn

H6P: GND, VDDCA, VDD1/2, VDD, VDD_CPU, VDD_GPU

VDDCA, VDD1/2, VDDQ



VDD



VDD_CPU, VDD_GPU



www.vinafix.vn

H6P (GND, VDDIO18, VDDIOD, VDD_SRAM, VDD_SOC)

JUST A FEW GNDS

U1
H6PPOP-1GB-DDR
SC58960X01-A030
FCMSP
SYM 12 OF 13
OMIT_TABLE

AN32 AN33 AN34 AP6 AP20 AP21 AP24 AP25 AP26 AP27 AP28 AP29 AP30 AP31 AP32 AR3 AR8 AR12 AR15 AR17 AR20 AR21 AR22 AR23 AR24 AR25 AR28 AR29 AR32 AT1 AT4 AT6 AT20 AT21 AT22 AT23 AT24 AT25 AT26 AT27 AT28 AT29 AT30 AT31 AT32 AU1 AU2 AU11 AU16 AU18 AU21 AU33 AU34 AV1 AV2 AV9 AV11 AV14 AV16 AV18 AV20 AV33 AV34 B1 B2 B4 B5 B6 B7 B8 B9 B10 B11 B12 B13 B15 B16 B17 B18 B19 B25 B28 B30 B33 B34 C1 C2 C3 C5 C6 C7 C9 — VSS

C10 C11 C12 C13 C15 C16 C17 C18 C19 C22 C23 C24 C26 C27 C29 C31 D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11 D12 D13 D15 D16 D17 D18 D19 D20 D21 D22 D32 E1 E3 E4 E5 E6 E7 E8 E9 E10 E11 E12 E13 E14 E15 E18 E19 E20 E21 E22 E31 E32 E34 F2 F3 F4 F5 F6 F7 F8 F9 F10 F12 F13 F14 F15 F26 F30 F31 G1 G3 G4 G5 G6 G7 G8 G9 G10 G11 G12 G13 G14 G15 G26 G28 — VSS

U1
H6PPOP-1GB-DDR
SC58960X01-A030
FCMSP
SYM 11 OF 13
OMIT_TABLE

A1 A2 A3 A4 A5 A7 A9 A11 A13 A14 A16 A18 A25 A28 A30 A33 A34 AA1 AA2 AA3 AA4 AA8 AA10 AA12 AA14 AA16 AA18 AA22 AA24 AA26 AA28 AA30 AB5 AB7 AB9 AB11 AB13 AB15 AB17 AB19 AB21 AB23 AB25 AB27 AB29 AB32 AC4 AC8 AC10 AC12 AC14 AC16 AC18 AC20 AC22 AC24 AC26 AC28 AC30 AC34 AD2 AD7 AD9 AD11 AD13 AD15 AD17 AD19 AD21 AD23 AD25 AD29 AD32 AE3 AE8 AE10 AE12 AE14 AE16 AE18 AE22 AE24 AE26 AE28 AF5 AF7 AF9 AF11 AF13 AF15 AF17 AF19 — VSS

AF21 AF23 AF29 AF32 AG2 AG8 AG10 AG12 AG14 AG16 AG18 AG20 AG22 AG24 AG26 AG28 AG30 AH5 AH7 AH9 AH11 AH13 AH15 AH17 AH19 AH21 AH23 AH25 AH27 AH29 AH32 AJ1 AJ3 AJ8 AJ10 AJ12 AJ14 AJ16 AJ18 AJ22 AJ24 AJ26 AJ28 AJ30 AK5 AK7 AK9 AK11 AK13 AK15 AK17 AK19 AK21 AK23 AK27 AK29 AK32 AL3 AL6 AL8 AL10 AL12 AL14 AL16 AL18 AL20 AL22 AL24 AL26 AL28 AL30 AM4 AM7 AM18 AM30 AN2 AN5 AN7 AB6 AM9 AM11 AM13 AN16 AM15 AN19 AN20 AN21 AN22 AN23 AN24 AN31 — VSS

VDDIOD, VDDIO18

24 12 4 2 PP1V2

CAPS FOR VDDIOD ARE SHARED WITH VDDQ

AM20 AM21 AM22 AM23 AM24 — VDDIOD_DDR0CA

R29 T29 U29 V29 — VDDIOD_DDR1CA

AA6 H6 H7 H8 H9 H10 H11 H12 H13 H14 H15 M6 N6 P6 R6 T6 U6 V6 W6 Y6 — VDDIOD_DDRDQ (1000MA)

OMIT_TABLE
U1
H6PPOP-1GB-DDR
SC58960X01-A030
FCMSP
SYM 9 OF 13

R33 T1 T2 T3 T5 T7 T9 T11 T13 T15 T17 T19 T21 T23 T25 T27 T30 T31 T32 T33 T34 U3 U5 U8 U10 U12 U14 U18 U20 U22 U24 U26 U28 U30 U34 V2 V3 V4 V5 V7 V9 V11 V13 V15 V17 V19 V21 V23 V25 V27 V30 V32 V34 W1 W2 W3 W4 W5 W8 W10 W12 W14 W16 W18 W20 W22 W24 W26 W28 W33 Y2 Y3 Y4 Y5 Y7 Y9 Y11 Y13 Y15 Y17 Y19 Y21 Y23 Y27 Y29 Y32 AM17 Y30 AC6 AE6 AG6 AJ6 AE30 — VSS

CAPS FOR VDDIO18_X ARE SHARED WITH VDDIODX

14 12 11 10 7 6 5 3 2 24 21 19 18 16 PP1V8

C30 4.7UF 20% 6.3V X5R 402 ROOM=H6P
C78 1UF 20% 4V X6S 0204 ROOM=H6P
C86 1UF 20% 4V X6S 0204 ROOM=H6P
C95 0.47UF 20% 4V X7S 0204 ROOM=H6P

AD6 AH6 AM8 AM10 AM12 AM14 AM16 AM19 — VDDIO18_GRP1 (65MA) (GPIO,UART,SPI,I2C) (SENSOR,SOCHOT,PMU)

AD30 AH30 — VDDIO18_GRP2 (20MA) (I2S,TMR,SIO,GPIO,UART)

G25 G27 H30 K30 M30 P30 G29 — VDDIO18_GRP3 (31MA) (PPN,GPIO,JTAG)

ROOM=H6P
FL67
1KOHM-25%-0.2A
0201

G24 — VDDIO18_GRP4 (2MA) (XTAL I/O)

PP1V8_XTAL
C379 1.0UF 20% 10V X5R-CERM 0201-1 ROOM=H6P

VDD_SRAM, VDD_SOC

U1
H6PPOP-1GB-DDR
SC58960X01-A030
FCMSP
SYM 8 OF 13
OMIT_TABLE

L4 L5 L6 L8 L10 L12 L14 L16 L18 L20 L22 L24 L26 L28 L30 L33 M1 M2 M3 M4 M5 M7 M9 M11 M13 M15 M17 M19 M21 M23 M25 M27 M29 M31 N2 N3 N4 N5 N8 N10 N12 N14 N16 N18 N20 N22 N24 N26 N28 N30 N33 P1 P2 P3 P4 P5 P7 P9 P11 P13 P15 P17 P19 P21 P23 P25 P27 P29 R2 R3 R4 R5 R8 R10 R12 R14 R16 R18 R20 R22 R24 R26 R28 R30 R31 — VSS

24 12 PP1V0_SRAM

C305 4.3UF 20% 4V X5R-CERM 0610 ROOM=H6P
C81 1UF 20% 4V X6S 0204 ROOM=H6P
C115 1UF 20% 4V X6S 0204 ROOM=H6P
C91 0.47UF 20% 4V X7S 0204 ROOM=H6P
C134 0.47UF 20% 4V X7S 0204 ROOM=H6P

AD24 AD26 AD28 AE23 AE25 AE27 AF24 AF26 AF28 AK25 Y25 — VDD_SRAM_CPU 1,500MA FOR CYCLONE + M$ SRAM @125C @1.0V

AA9 AA11 AA13 AA15 AB8 T8 T10 T12 U9 U11 U13 V8 V10 V12 W9 W11 W13 W15 Y8 Y10 Y12 Y14 — VDD_SRAM_SOC (1500MA)

16 14 12 11 10 7 6 5 3 2 24 21 19 18 PP1V8

C85 0.1UF 20% 6.3V X5R-CERM 01005 ROOM=H6P

AJ20 AA20 AB4 H22 — VDD_ANA_TMPSADC0(2.5MA) VDD_ANA_TMPSADC1(2.5MA) VDD_ANA_TMPSADC2(2.5MA) VDD_ANA_TMPSADC3(2.5MA)

www.vinafix.vn

H6P NAND + 12X17 NAND PKG

SUPPORT FOR PPN1.5 (1.8V IO) ONLY

PCB: THIS XW ON OUTER LAYER, ACCESSIBLE FOR REWORK

XW2 SM ROOM=NAND

PP3V0_NAND_XW → PP3V0_NAND

C180 0.47UF 20% 4V X7S 0204 ROOM=NAND
C3 1UF 20% 4V X6S 0204 ROOM=NAND
C185 1UF 20% 4V X6S 0204 ROOM=NAND
C182 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=NAND OMIT_TABLE
C307 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=NAND OMIT_TABLE
C209 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=NAND OMIT_TABLE
C187 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=NAND OMIT_TABLE

PP1V8

PP1V2_NAND_VDDI
C50 2.2UF 20% 4V X5R-CERM 0201 ROOM=NAND

1000MA 500MA

C376 2.2UF 20% 4V X5R-CERM 0201 ROOM=NAND
C377 15UF 20% 4V X5R 0402 ROOM=NAND
C378 15UF 20% 4V X5R 0402 ROOM=NAND
C999 10UF 20% 4V X5R-CERM 0402-1 ROOM=NAND

OMIT_TABLE ROOM=NAND

NOSTUFF R160 100K 5% 1/32W MF 01005 ROOM=NAND
NOSTUF R161 100K 5% 1/32W MF 01005 ROOM=NAND

PP1V8 → R78 100K 5% 1/32W MF 01005 ROOM=H6P

AP_TO_NAND_ANC0_CEN0_L → U1.PPN0_CEN0 (G32), U1.PPN0_CEN1 (H31)

R82 100K 5% 1/32W MF 01005 ROOM=H6P
AP_TO_NAND_ANC1_CEN0_L → U1.PPN1_CEN0 (R32), U1.PPN1_CEN1 (P32)

C136 0.01UF 10% 6.3V X5R 01005 ROOM=H6P
C144 0.01UF 10% 6.3V X5R 01005 ROOM=H6P

R137 50K 1% 1/32W MF 01005 ROOM=H6P
R143 50K 1% 1/32W MF 01005 ROOM=H6P
AP_TO_NAND_ANC_DQVREF

U1 H6PPOP-1GB-DDR SC58960X01-A030 FCMSP SYM 4 OF 13 OMIT_TABLE

U1			U1
AP_BI_NAND_ANC0_IO<0>	B32	PPN0_IO0	PPN1_IO0 M34 — AP_BI_NAND_ANC1_IO<0>
AP_BI_NAND_ANC0_IO<1>	C32	PPN0_IO1	PPN1_IO1 M33 — AP_BI_NAND_ANC1_IO<1>
AP_BI_NAND_ANC0_IO<2>	C33	PPN0_IO2	PPN1_IO2 L32 — AP_BI_NAND_ANC1_IO<2>
AP_BI_NAND_ANC0_IO<3>	C34	PPN0_IO3	PPN1_IO3 M32 — AP_BI_NAND_ANC1_IO<3>
AP_BI_NAND_ANC0_IO<4>	F32	PPN0_IO4	PPN1_IO4 K32 — AP_BI_NAND_ANC1_IO<4>
AP_BI_NAND_ANC0_IO<5>	F33	PPN0_IO5	PPN1_IO5 J32 — AP_BI_NAND_ANC1_IO<5>
AP_BI_NAND_ANC0_IO<6>	F34	PPN0_IO6	PPN1_IO6 H33 — AP_BI_NAND_ANC1_IO<6>
AP_BI_NAND_ANC0_IO<7>	G34	PPN0_IO7	PPN1_IO7 H34 — AP_BI_NAND_ANC1_IO<7>
AP_TO_NAND_ANC0_ALE	A31	PPN0_ALE	PPN1_ALE N34 — AP_TO_NAND_ANC1_ALE
AP_TO_NAND_ANC0_CLE	B31	PPN0_CLE	PPN1_CLE P31 — AP_TO_NAND_ANC1_CLE
AP_TO_NAND_ANC0_WE_L	A32	PPN0_WEN	PPN1_WEN N32 — AP_TO_NAND_ANC1_WE_L
45_AP_TO_NAND_ANC0_RE_L	D33	PPN0_REN	PPN1_REN L31 — 45_AP_TO_NAND_ANC1_RE_L
45_AP_BI_NAND_ANC0_DQS	D34	PPN0_DQS	PPN1_DQS L34 — 45_AP_BI_NAND_ANC1_DQS
45_AP_PPN0_ZQ	E33	PPN0_ZQ	PPN1_ZQ K33 — 45_AP_PPN1_ZQ
AP_TO_NAND_ANC_DQVREF	D31	PPN0_VREF	PPN1_VREF N31 — AP_TO_NAND_ANC_DQVREF

VDDI018_GRP3

R153 240 1% 1/32W MF 01005 ROOM=H6P
R55 240 1% 1/32W MF 01005 ROOM=H6P

U4			U4
AP_BI_NAND_ANC0_IO<0>	G3	IO0-0	IO0-1 — AP_BI_NAND_ANC1_IO<0>	G1
AP_BI_NAND_ANC0_IO<1>	H2	IO1-0	IO1-1 — AP_BI_NAND_ANC1_IO<1>	J1
AP_BI_NAND_ANC0_IO<2>	J3	IO2-0	IO2-1 — AP_BI_NAND_ANC1_IO<2>	L1
AP_BI_NAND_ANC0_IO<3>	K2	IO3-0	IO3-1 — AP_BI_NAND_ANC1_IO<3>	N3
AP_BI_NAND_ANC0_IO<4>	L5	IO4-0	IO4-1 — AP_BI_NAND_ANC1_IO<4>	N5
AP_BI_NAND_ANC0_IO<5>	K6	IO5-0	IO5-1 — AP_BI_NAND_ANC1_IO<5>	L7
AP_BI_NAND_ANC0_IO<6>	J5	IO6-0	IO6-1 — AP_BI_NAND_ANC1_IO<6>	J7
AP_BI_NAND_ANC0_IO<7>	H6	IO7-0	IO7-1 — AP_BI_NAND_ANC1_IO<7>	G7
AP_TO_NAND_ANC0_CEN0_L	A5	CE0*	CE1*	C5 — AP_TO_NAND_ANC1_CEN0_L
AP_TO_NAND_ANC0_CLE	A3	CLE0	CLE1	C3 — AP_TO_NAND_ANC1_CLE
AP_TO_NAND_ANC0_ALE	C1	ALE0	ALE1	D2 — AP_TO_NAND_ANC1_ALE
AP_TO_NAND_ANC0_WE_L	E3	WE0*	WE1*	E1 — AP_TO_NAND_ANC1_WE_L
	B4	RE0	RE1	D4
45_AP_TO_NAND_ANC0_RE_L	C7	RE0*	RE1*	D6 — 45_AP_TO_NAND_ANC1_RE_L
45_AP_BI_NAND_ANC0_DQS	H4	DQS0	DQS1	M4 — 45_AP_BI_NAND_ANC1_DQS
	F4	DQS0*	DQS1*	K4
NAND_RDYBSY0	E5	R/B0*	R/B1*	E7 — NAND_RDYBSY1
AP_TO_NAND_ANC_DQVREF	G5	VREF	
45_NAND_PPN_ZQ	A1	ZQ	

XXNM-XGBX8-MLC-PPN1.5-ODP

PP17 P4MM-NSM SM ROOM=NAND — NAND_TO_PP_TCKC — OA0 TCKC
PP19 P4MM-NSM SM ROOM=NAND — NAND_TO_PP_TMSC — OB0 TMSC

VSS: B2 F6 L3
VSSQ: A7 M2 OC9 OD9 OE8 OF9 G8

R8 243 1% 1/32W MF 01005 ROOM=NAND

NOTE: NAND PADS SHOULD BE SHIELDED FROM TRACES WITH A GROUND PLANE

NOTE: IO<6> PREFERRED BY MATT BYOM (IS A STATUS READY BIT)

PP2 P4MM-NSM SM ROOM=H6P — AP_BI_NAND_ANC0_IO<6>
PP3 P4MM-NSM SM ROOM=H6P — 45_AP_TO_NAND_ANC0_RE_L
PP10 P4MM-NSM SM ROOM=H6P — 45_AP_BI_NAND_ANC0_DQS

www.vinafix.vn

H6P HIGH SPEED DIG (CAM, LCD, DP)





www.vinafix.vn

BUTTON FLEX (VIBE DRIVER, BUTTONS, ANC REF MIC, STROBE, STROBE_NTC)



www.vinafix.vn

L67 AUDIO CODEC

AUDIO I/O

(ANALOG MIC IN, DIG MIC IN, HPOUT, LINEOUT, RECEIVER OUT, MIKEYBUS)



www.vinafix.vn

L67 AUDIO CODEC

POWER, MICBIAS



DIGITAL SYSTEM I/O



www.vinafix.vn

FRONT CAM FLEX B2B (FCAM, PROX, ALS, RECEIVER, ANC ERROR MIC)

FCAM:
CLK, I2C, SHDN

PROX: POWER,
RX, RX_EN

ALS: POWER,
I2C, INT

HAC

RECEIVER

NOTE: CONN GENDER SWAPPED AT PROTO2
THIS ON ONE MLB ---> 516S0986 RCPT
516S0987 PLUG (FLEX)

PCB: PLACE THESE AT J1 CONN

FCAM:
POWER AND MIPI

MIC3
(ANC ERROR MIC)

FCAM ALS INT

PROX: PWR, TX EN

PROX_RX SIGNAL MUST BE TREATED WITH CARE

IRLED = 104-128MA

SPECIAL Z = 0.60 MM MAX

NOTE: J1.29 IS GND ON POR BOARDS,
J1.29 IS ALS_INT FROM FF CAM FOR
SPECIAL CONFIG OF PROTO2
(CONTROLLED VIA BOMOPTION)

www.vinafix.vn

AMBER PMU

(BUCK, LDO, VIBE DRIVER, 32K, CHARGER)

TO DO: GEERTJAN TO UPDATE VALUE
OF R70 WITH H6P (EXPECTED TO CHANGE)

R70 68.1K 1/32W MF 01005 ROOM=PMU
USB_VBUS_DETECT
TRISTAR_TO_PMU_OVP_SW_EN_L
NOTE: THIS SIGNAL (ACT HI) WILL OPEN VBUS
PP_PMU_VCENTER
C3096 56PF 5% 16V NP0-C0G 01005 ROOM=PMU
C204 10UF 20% 6.3V CERM-X5R 0402-2 ROOM=PMU
C281 10UF 20% 6.3V CERM-X5R 0402-2 ROOM=PMU
PP5V0_USB_PROT
C272 1UF 10% 16V X5R 402 ROOM=PMU
PP_BATT_VCC
Q4 APN: 376S1131
Q4 CSD68815W15 BGA ROOM=PMU
C33 C32 C31 B3 B2 B1 A3 A2 A1
L8 2.2UH-20%-1.7A-200MOHM TFA201610G-PSE20161T2R2 OMIT_TABLE
PP_PMU_VSW_CHG
BATTERY_TO_PMU_SENSE
PMU_ACT_DIO
PP_VCC_MAIN
C266 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
C357 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C358 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C260 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C263 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C267 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C270 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C261 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C264 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C268 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C271 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C385 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C398 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C411 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
PP1V2_SDRAM
C278 1UF 10% 6.3V CERM 402 ROOM=PMU
PP_VCC_MAIN
PP_PMU_TO_VIBE
AP_TO_PMU_VIBE_PWM_EN
C96 56PF 5% 16V NP0-C0G 01005 ROOM=PMU
C343 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
45_PMU_TO_XTAL_OSC32
45_XTAL_TO_PMU_OSC32
Y2 32.768K-20PPM-12.5PF 2012 ROOM=PMU
C276 18PF 5% 16V CERM 01005 ROOM=PMU
C283 18PF 5% 16V CERM 01005 ROOM=PMU
XW1 SHORT-10L-0.1MM-SM ROOM=PMU
PCB: PLACE THIS XW AT C276/C283
45_AMBER_VSS_RTC
PP_VCC_MAIN
C399 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C405 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C417 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C418 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C250 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C251 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE
C325 10UF 20% 6.3V CERM-X5R 0402-1 ROOM=PMU OMIT_TABLE

U7 AMBER-PMC FCCSP-0.84MM (1 OF 3)

F5 VBUS_OVP_OFF 80-300K INT PU TO VBUS
K1 K2 VCENTER
L1 L2 M1 M2 VBUS
F1 F2 IBAT
E2 VBAT
C1 ACT_DIO
J1 J2 CHG_LX
G1 G2 VCC_MAIN
D2 VCC_MAIN_S
BAT/USB

A16 B16 C4 VDD_BUCK1
F20 C16 VDD_BUCK1_2
A13 B13 C13 VDD_BUCK2
F21 VDD_BUCK3
A20 B20 C20 VDD_BUCK4
K20 K21 VDD_BUCK5
A4 B4 VDD_BUCK001
A9 B9 C9 VDD_BUCK023
BUCK INPUT

M12 VDD_LDO6
N13 VDD_LDO2
M6 VDD_LDO1_3
M7 VDD_LDO4_7
M14 VDD_LDO5
M8 VDD_LDO8_9
M10 VDD_LDO10
M11 VDD_LDO11_13
LDO INPUT

N5 VDD_VIB
P5 VIB
M5 VIB_PWM_EN 50-100K INT PD
VIBE

D1 XTAL1
E1 XTAL2
G10 VSS_RTC
XTAL

SAME POLARITY
L9 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
L10 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
L11 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
L12 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
NOTE: L10, L12 BOMOPTIONS CONTROLLED ON PAGE1
C290 C292 C294 C135 15UF 20% 4V X5R 0402 ROOM=PMU
C296 C145 C162 15UF 20% 4V X5R 0402 ROOM=PMU
C128 C181 C262 15UF 20% 4V X5R 0402 ROOM=PMU
R11 10 NOSTUFF 5% 1/32W MF 01005 ROOM=PMU
PCB: R11 LOCAL FEEDBACK FOR TESTING
PP_BUCK0_LX0
PP_BUCK0_LX1
PP_BUCK0_LX2
PP_BUCK0_LX3
45_BUCK0_FB
BUCK0_LX0 BUCK0_LX1 BUCK0_LX2 BUCK0_LX3 BUCK0_FB

H6 VDD_CPU 10.8A MAX

SAME POLARITY
L13 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
L14 0.47UH-20%-3.2A-0.0460HM TFA201610G-SM ROOM=PMU
C303 C127 C310 15UF 20% 4V X5R 0402 ROOM=PMU
R115 10 NOSTUFF 5% 1/32W MF 01005 ROOM=PMU
PCB: THIS RESISTOR FOR LOCAL FEEDBACK
C301 C58 15UF 20% 4V X5R 0402 ROOM=PMU
PP_BUCK1_LX0
PP_BUCK1_LX1
45_BUCK1_FB
BUCK1_LX0 BUCK1_LX1 BUCK1_FB

H6 VDD_GPU PMU: 5.0A MAX

L15 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
NOTE: PP1V0_SOC STATIC AT 1.0V. NO DVFM ON THIS RAIL PER SEG.
R117 10 NOSTUFF 5% 1/32W MF 01005 ROOM=PMU
C123 C175 C189 15UF 20% 4V X5R 0402 ROOM=PMU
PP_BUCK2_LX
45_BUCK2_FB
BUCK2_LX BUCK2_FB

H6 VDD 2.5A MAX

PP_BUCK3_LX
45_BUCK3_FB
PP1V8
BUCK3_LX BUCK3_FB BUCK3_SW1 BUCK3_SW2 BUCK3_SW3 VBUCK3_SW
PP1V8_GRAPE
PP1V8_OSCAR
PP_BUCK4_LX
PP1V2
PP1V2_OSCAR
45_BUCK4_FB
BUCK4_LX BUCK4_FB BUCK4_SW1 BUCK4_SW2 VBUCK4_SW
PP_BUCK5_LX
45_BUCK5_FB
BUCK5_LX BUCK5_FB

VLDO1 (50MA) 2.5V-3.3V, +/-77.5MV
VLDO2 (50MA) 1.2V-1.9V, +/-42.5MV
VLDO3 (50MA) 2.5V-3.3V, +/-75MV
VLDO4 (50MA) 2.5V-3.6V, +/-75MV
VLDO5 (1000MA) 2.5V-3.6V, +/-75MV
VLDO6 (150MA) 1.2V-3.6V, +/-82.5MV
VLDO7 (250MA) 2.5V-3.6V, +/-75MV
VLDO8 (250MA) 2.5V-3.6V, +/-70MV
VLDO9 (250MA) 2.5V-3.6V, +/-71.25MV
VLDO9_FB
VLDO10 (100MA) 0.6V-1.4V, +/-25MV
VLDO11 (250MA) 2.5V-3.6V, +/-82.5MV
VLDO12 (5MA) FIXED 1.8V, +/-5%
VLDO13 (250MA) 2.5V-3.6V, +/-71.25MV
VPUMP
45_PMU_VPUMP
LDO

VPUMP CAP: SPEC REQUIRES 10NF, 50% DERATED VPUMP RUNS AT 4.6V
C10 0.1UF 20% 6.3V X5R-CERM 01005 ROOM=PMU
C104 C109 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
C299 4.7UF 20% 6.3V X5R-CERM1 402 ROOM=PMU
C207 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
C16 4.7UF 20% 6.3V X5R-CERM1 402 ROOM=PMU
REMOVED LDO9 CAPS PER RDAR://12552087
CHANGED LDO8 CAP PER RDAR://12525301
C442 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
C24 4.7UF 20% 6.3V X5R-CERM1 402 ROOM=PMU
C291 0.1UF 20% 6.3V X5R-CERM 01005 ROOM=PMU
C419 1.0UF 20% 6.3V X5R 0201-1 ROOM=PMU
CHANGED LDO11 CAP PER RDAR://12518153

H6 VDD1(BUCK3)=0.945A MAX
BUCK3_SW1=0.500A MAX
BUCK3_SW2=0.?A MAX
BUCK3_SW3=0.?A MAX
TOTAL=0.545A MAX
L16 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
XW18 SHORT-10L-0.1MM-SM ROOM=PMU
C293 C443 15UF 20% 4V X5R 0402 ROOM=PMU
PP1V8_SDRAM

H6 VDDCA_VDD2
(BUCK4)=0.500A MAX
BUCK4_SW1=1.000A MAX
BUCK4_SW2=0.100A MAX
TOTAL=1.600A MAX
L17 1.0UH-20%-2.5A-0.075OHM TFA201610G-SM ROOM=PMU
XW20 SHORT-10L-0.1MM-SM ROOM=PMU
C308 C316 15UF 20% 4V X5R 0402 ROOM=PMU
PP1V2_SDRAM

H6 VDD_SRAM, VDD_SRAM_SOC 1.5A MAX
L18 1.0UH-20%-2.2A-0.170OHM TFA201210G-SM ROOM=PMU
XW3 SHORT-10L-0.1MM-SM ROOM=PMU
NOTE: PP1V0_SRAM STATIC AT 1.0V. NO DVFM ON THIS RAIL PER SEG.
C140 C66 C327 15UF 20% 4V X5R 0402 ROOM=PMU
PP1V0_SRAM

NOTE: 6 TURNS OF PP2V5_RCAM_AF_COMP WAS THE MAGIC NUMBER FOR N41.
PLACE AT PMU AREA
THIS VALUE NEEDS TUNING LATER
R119 10 2 1% 1/32W MF 01005 ROOM=PMU
PP2V5_RCAM_AF
PP2V5_RCAM_AF_COMP
XW10 SM ROOM=PMU
PGND_RCAM_AF_RET
THIS XW LINK AT PMU AREA

TO DO: REVIEW ALL LDO ASSIGNMENTS
(CHECK VDD_LDO INPUT SOURCE
CHECK CURRENT RATING FOR LDO OUT
VS. LOAD REQUIREMENT AT DESTINATION, ETC)

PP3V3_USB SOC USB PHY (25 MA)
PP1V8_VA_L19_L67 SPEAKER AMP, CODEC VA (2.5 MA L19, 3MA L67)
PP3V0_SDRAM TRISTAR VDH, WIFI_FLEX PAC (NOTE: 3V +/- 5% PER EUGENE
PP3V0_TMU GYRO, ACCEL, COMPASS (? MA)
PP3V0_NAND NAND (? MA)
PP3V0_ACC ACCESSORY POWER (? MA)
PP3V0_PROX_ALS PROX/ALS VDD (PROX: 0.75/1.2 MA ALS: 0.175/0.25 MA [TYP/MAX])
PP2V5_RCAM_AF REAR CAM AUTO FOCUS (120MA PEAK, PROBABLY CAP AT 80MA)
PP2V85_CAM_AVDD REAR/FRONT CAM AVDD (? MA)
45_CAM_AVDD_FB
PP1V0 SOC 1V0 MIPI, USB_DVDD, DP (71 MA TOTAL)
PP3V0_PROX_IRLED PROX LED (102 MA TYP)
PP1V8_ALWAYS ALWAYS ON 1V8 (? MA)
PP3V0_NAVA10

www.vinafix.vn

AMBER PMU

(AMUX, GPIO, BUTTONS, ADC, THERMISTORS, SYSTEM I/F, GND)



www.vinafix.vn

CHESTNUT, BACKLIGHT DRIVER, MESA BOOST

CHESTNUT BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
338S1172	1	TI CHESTNUT	U3	Y	CHESTNUT_TI
152S1842	1	TI CHESTNUT IND - 1.5UH TAIYO	L19	Y	CHESTNUT_TI_TAIYO
152S1802	1	TI CHESTNUT IND - 1.5UH CYNTEC	L19	Y	CHESTNUT_TI_CYNTEC
338S1168	1	INTERSIL CHESTNUT	U3	Y	CHESTNUT_INTERSIL
152S1805	1	INTERSIL CHESTNUT IND - 2.2UH TFA-A	L19	Y	CHESTNUT_INTERSIL_TFA-A

D403 DISPLAY PMU (INTERSIL CHESTNUT, 338S1148) (TI CHESTNUT, 338S1149)



SAGE NEG BOOST TIMING INFO:

2 MS NOMIAL START UP DELAY FOR LCM POWER SEQUENCING
0 MS DELAY AT SHUTDOWN
ACTIVE DISCHARGE 2MS TO RAIL DOWN

D403 BACKLIGHT DRIVER



NOTE: STACKED TO MEET VOLTAGE REQ, LOOK INTO 18+V CAPS

MESA BOOST



NOTE: LT3460 SPEC RECOMMENDS TO TIE PINS 2,5 TO GND

www.vinafix.vn

SPEAKER AMP, LED DRIVER

SPEAKER AMP (TO BE REPLACED WITH L20)



STROBE DRIVER (OPEL)

TI: APN 353S3899
FAIRCHILD: APN 353S3839



www.vinafix.vn

TRISTAR



EEPROM



www.vinafix.vn

DOCKFLEX B2B (USB VBUS, MENU BTN, SPEAKER, HP, HP EXTMIC, NAVAJO, ANTENNA LAT SW CTRL, MIC1 (PRIMARY MIC), ACC DET/ID/PWR, E75 DIFFPAIRS)

NAVAJO:
VDD(1.8V)
VBOOST(18V)
BOOST_EN

HPHONE:
HS3/HS4,
HPDET,
HS3/HS4 REF,
(+EXTMIC)
HS3/HS4 CTRL

MENU BUTTON

MIC1
(PRIMARY MIC)

ANTENNA:
PAC 2.65V

SPEAKER:
SPEAKER LEADS
VSENSE,

USB VBUS

NAVAJO:
VDD (3.0V)
SPI

HPHONE AUDIO

BATTERY NTC

ANTENNA:
LAT SW CTRL

E75 DIFFPAIRS

ACCESSORY:
DETECT,
ID, PWR

PP1V8_SDRAM
PP18V0_MESA
MESA_TO_BOOST_EN
HPHONE_TO_CODEC_DET
FL33 70-OHM-300MA 01005-1 ROOM=DOCK
FL54 70-OHM-300MA 01005-1 ROOM=DOCK
FL66 120-OHM-210MA 01005 ROOM=DOCK
TO DO: C110 16V FOR NOW. NEED 25V RATING
C184 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C110 56PF 5% 25V NP0-C0G 01005 ROOM=DOCK
C116 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
R107 3.3K 5% 1/32W MF 01005 ROOM=DOCK
HPHONE_TO_CODEC_DET
FL1 120-OHM-210MA 01005 ROOM=DOCK
FL10 120-OHM-210MA 01005 ROOM=DOCK
CODEC_TO_HPHONE_HS3
CODEC_TO_HPHONE_HS4
CODEC_TO_HPHONE_HS3_CONN
CODEC_TO_HPHONE_HS4_CONN
C242 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C8 100PF 5% 16V NP0-C0G 01005 ROOM=DOCK
C5 100PF 5% 16V NP0-C0G 01005 ROOM=DOCK
EXTMIC_TO_CODEC_P
EXTMIC_TO_CODEC_N
C4 NOSTUFF 220PF 10% 10V X7R-CERM 01005 ROOM=DOCK
R15 0.00 0% 1/32W MF 01005 ROOM=DOCK
R50 0.00 0% 1/32W MF 01005 ROOM=DOCK
FL16 120-OHM-210MA 01005 ROOM=DOCK
FL17 120-OHM-210MA 01005 ROOM=DOCK
CODEC_TO_HPHONE_HS4_REF
CODEC_TO_HPHONE_HS3_REF
DZ12 6.8V-100PF 01005 ROOM=DOCK
DZ11 6.8V-100PF 01005 ROOM=DOCK
FL69 150OHM-25%-200MA-0.7DCR 01005 ROOM=DOCK
AP_TO_HEADSET_HS3_CTRL
FL68 150OHM-25%-200MA-0.7DCR 01005 ROOM=DOCK
AP_TO_HEADSET_HS4_CTRL
AP_TO_HEADSET_HS3_CTRL_CONN
AP_TO_HEADSET_HS4_CTRL_CONN
DZ9 6.8V-100PF 01005 ROOM=DOCK
DZ10 6.8V-100PF 01005 ROOM=DOCK
BUTTON_TO_AP_MENU_KEY_L
FL5 120-OHM-210MA 01005 ROOM=DOCK
C176 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
DZ15 12V-33PF 01005-1 ROOM=DOCK NOSTUFF 50NA @ 2.5V
BUTTON_TO_AP_MENU_KEY_CONN_L
PP_CODEC_TO_MIC1_BIAS
FL49 120-OHM-210MA 01005 ROOM=DOCK
PP_CODEC_TO_MIC1_BIAS_CONN
C215 1.0UF 20% 6.3V X5R 0201-1 ROOM=DOCK
PGND_MIC1_TO_CODEC_RET
PLACE UNDER CONN
XW25 SHORT-10L-0.1MM-SM
C355 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C359 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
XW45 SHORT-10L-0.1MM-SM ROOM=DOCK
PCB: PUT XW AT J7.17
MIC1_TO_CODEC_N
MIC1_TO_CODEC_P
PP_LDO14_2P65
SPEAKER_TO_SPKAMP_VSENSE_P
SPEAKER_TO_SPKAMP_VSENSE_N
SPKAMP_TO_SPEAKER_OUT_CONN_P
SPKAMP_TO_SPEAKER_OUT_CONN_N
Q2 CSD68813W10 BGA ROOM=DOCK
Q2 APN: 376S1130 39MOHM MAX AT -4.5V VGS
A2 B2 A1 B1 G1 G2 D1 D2
REVERSE_GATE
PP5V0_USB_PROT
POWER TO TRISTAR AND PMU
R58 5.1K 5% 1/20W MF 201 ROOM=DOCK
NOTE: KEEP R58 AT 0201 FOR POWER DISSIPATION IN CASE OF -20V RVP EVENT
C368 0.01UF 10% 25V X5R-CERM 0201 ROOM=DOCK
C12 100PF 5% 16V NP0-C0G 01005 ROOM=DOCK
C13 100PF 5% 16V NP0-C0G 01005 ROOM=DOCK
PP5V0_USB_CONN
USB_CONN_SNUB
PCB: PLACE AT J7.GND PIN (PCB CAN CHOOSE)
XW13 SM ROOM=DOCK
CODEC_MBUS_REF
THIS ONE ON MLB ---> 516S1032 PLUG
516S1031 RCPT (USED ON FLEX)
J7 105847038102829 M-ST-SM ROOM=DOCK
SPKAMP_TO_SPEAKER_OUT_CONN_P
PP1V8_SDRAM_DOCK_CONN
PP18V0_MESA_DOCK_CONN
MESA_TO_BOOST_EN_DOCK_CONN
AP_TO_NAVAJO_SPI2_MOSI_CONN
NAVAJO_TO_PMU_INT_CONN_H
BB_TO_LAT_SW3_CTL
NOTE: RSVD ANTENNA
HPHONE_TO_CODEC_DET_CONN
NOTE: HS4_CONN
CODEC_TO_HPHONE_HS4_REF_CONN
CODEC_TO_HPHONE_HS3_REF_CONN
NOTE: HS3_CTRL
BUTTON_TO_AP_MENU_KEY_CONN_L
NOTE: MIC1_BIAS
NOTE: MIC1_P
NOTE: MIC1_RETURN
NOTE: PAC 2.65V
NOTE: SPKR_P
NOTE: SPKR_N
NOTE: NAVAJO MISO
PP3V0_NAVAJO_CONN
AP_TO_HEADSET_HS4_CTRL_CONN
CODEC_TO_HPHONE_L
CODEC_TO_HPHONE_R
CODEC_TO_HPHONE_HS3_CONN
BATTERY_NTC_CONN
AP_TO_NAVAJO_SPI2_CLK_CONN
NOTE: LAT_SW2
NOTE: LAT_SW1
90_TRISTAR_BI_E75_PAIR1_CONN_P
90_TRISTAR_BI_E75_PAIR1_CONN_N
90_TRISTAR_BI_E75_PAIR2_CONN_N
90_TRISTAR_BI_E75_PAIR2_CONN_P
E75_TO_PMU_ACC_DETECT_CONN
PP_E75_TO_TRISTAR_ACC1_CONN
PP_E75_TO_TRISTAR_ACC2_CONN
NOTE: PP5V0_USB_CONN
PCB: PLACE THESE XW LINKS AT DOCK CONNECTOR
XW21 SM ROOM=DOCK
XW22 SM ROOM=DOCK
PCB: PLACE NEAR J7 (DESENSE CAPS)
C70 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C71 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C240 27PF 5% 16V NP0-C0G 01005 ROOM=DOCK
DZ14 6.8V-100PF 01005 ROOM=DOCK
DZ13 6.8V-100PF 01005 ROOM=DOCK
PCB: PLACE NEAR J7 (ESD + DESENSE!)
C99 56PF 5% 16V NP0-C0G 01005 ROOM=DOCK
C102 56PF 5% 16V NP0-C0G 01005 ROOM=DOCK
PCB: PLACE ON TOP OF L20, L22 FOOTPRINT
0OHM PLACEHOLDERS FOR E75 PAIRS TO REDUCE OVERALL DCR ON USB
R165 0.00 0% 1/32W MF 01005 ROOM=DOCK
R168 0.00 0% 1/32W MF 01005 ROOM=DOCK
R166 0.00 0% 1/32W MF 01005 ROOM=DOCK
R167 0.00 0% 1/32W MF 01005 ROOM=DOCK
AP_TO_NAVAJO_SPI2_MOSI
AP_TO_NAVAJO_SPI2_CLK
NAVAJO_TO_AP_SPI2_MISO
NAVAJO_TO_PMU_INT_H
FL32 120-OHM-210MA 01005 ROOM=DOCK
FL63 120-OHM-210MA 01005 ROOM=DOCK
FL50 120-OHM-210MA 01005 ROOM=DOCK
FL59 120-OHM-210MA 01005 ROOM=DOCK
C103 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C101 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C126 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C98 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
NOTE: NOSTUFF FL19 FOR PROTO1A/2 NEED DAISY CHAIN GPIO INSTEAD
FL19 NOSTUFF 80-OHM-25%-1000MA 0201 ROOM=DOCK
NOTE: 0.130HM DCR
PP3V0_NAVAJO
C119 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C105 0.1UF 20% 6.3V X5R-CERM 01005 ROOM=DOCK
R135 0.00 0% 1/32W MF 01005 ROOM=DOCK
AP_TO_NAVAJO_DAISY_CHAIN
L7 FERR-33-OHM-0.8A-0.09-OHM 0201 ROOM=DOCK
C374 6.8V-100PF 01005 ROOM=DOCK
R23 100K 1% 1/32W MF 01005 ROOM=DOCK
HPHONE_TO_CODEC_HPHONE_TEST
R10 100K 1% 1/32W MF 01005 ROOM=DOCK
L6 FERR-33-OHM-0.8A-0.09-OHM 0201 ROOM=DOCK
C375 6.8V-100PF 01005 ROOM=DOCK
CODEC_TO_HPHONE_L
CODEC_TO_HPHONE_R
FL2302 120-OHM-210MA 01005 ROOM=DOCK
BATTERY_TO_PMU_NTC
C2307 56PF 5% 16V NP0-C0G 01005 ROOM=DOCK
BB_TO_LAT_SW2_CTL
BB_TO_LAT_SW1_CTL
BB_TO_LAT_SW3_CTL
C188 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C206 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
C14 56PF 5% 6.3V NP0-C0G 01005 ROOM=DOCK
L20 90-OHM-50MA TCM0605-1 SYM_VER_2 ROOM=DOCK
OMIT_TABLE
L22 90-OHM-50MA TCM0605-1 SYM_VER_2 ROOM=DOCK
OMIT_TABLE
R130 1.00K 1% 1/32W 01005 5% MF
E75_TO_PMU_ACC_DETECT
FL60 10-OHM-750MA 01005-1 ROOM=DOCK
PP_E75_TO_TRISTAR_ACC1
FL53 10-OHM-750MA 01005-1 ROOM=DOCK
PP_E75_TO_TRISTAR_ACC2

www.vinafix.vn

D403 (B2B,DRIVER ICS)

CUMULUS C1

343S0638

(TURN ON LATER THAN PP1V8_GRAPE)
(TURN OFF SAME TIME AS PP1V8_GRAPE)

PP5V1_GRAPE_VDDH
PP_CUMULUS_VDDCORE
PP_CUMULUS_VDDANA
PP1V8_CUMULUS_VDDLDO
PP_SAGE_TO_TOUCH_VCPL
PN5V7_SAGE_AVDDN
PP5V7_SAGE_AVDDH
PP_SAGE_TO_TOUCH_VCPH
PP1V8_GRAPE
PP_SAGE_VCPL_F
PP_SAGE_VBST_OUTH
PP_SAGE_VBST_OUTL
PP_SAGE_LX
PP_SAGE_LY

C369 10UF 20% 10V X5R-CERM 0402-1 ROOM=CUMULUS
C370 4.7UF 20% 6.3V X6S-CERM1 402 ROOM=CUMULUS
C371 4.7UF 20% 6.3V X6S-CERM1 402 ROOM=CUMULUS
C372 1.0UF 20% 6.3V X5R 0201-1 ROOM=CUMULUS
XW36 SM ROOM=CUMULUS
R86 220K 5% 1/32W MF 01005 ROOM=CUMULUS

45_PROX_TO_CUMULUS_RX
45_PROX_TO_CUMULUS_RX_FILT
C79 1000PF 10% 6.3V X5R-CERM 01005
R26 22.1K 1% 1/32W MF 01005 ROOM=CUMULUS
C130 27PF 5% 16V NP0-C0G 01005 ROOM=CUMULUS

CUMULUS_IN IS SENSITIVE

SAGE_TO_CUMULUS_IN<2>	B9	IN0_0	
SAGE_TO_CUMULUS_IN<1>	B8	IN1_0	
SAGE_TO_CUMULUS_IN<6>	A9	IN2_0	
SAGE_TO_CUMULUS_IN<7>	B7	IN3_0	
SAGE_TO_CUMULUS_IN<4>	B6	IN4_0	
SAGE_TO_CUMULUS_IN<8>	A8	IN5_0	
SAGE_TO_CUMULUS_IN<3>	B5	IN6_0	
SAGE_TO_CUMULUS_IN<5>	B4	IN7_0	
SAGE_TO_CUMULUS_IN<9>	A7	IN8_0	
SAGE_TO_CUMULUS_IN<0>	B3	IN9_0	
SAGE_TO_CUMULUS_IN<14>	A6	IN10_0	
SAGE_TO_CUMULUS_IN<10>	A3	IN11_0	
SAGE_TO_CUMULUS_IN<13>	A5	IN12_0	
SAGE_TO_CUMULUS_IN<11>	A4	IN13_0	
SAGE_TO_CUMULUS_IN<12>	B2	IN14_0	
45_PROX_TO_CUMULUS_RX_IN	A2	IN14_1	

U12 CUMULUS-C1 WLBGA
CUMULUS C1 SILICON RDAR://12551355

VSTM_0	E9	CUMULUS_TO_SAGE_VSTM_OUT<2>	
VSTM_1	E5	CUMULUS_TO_SAGE_VSTM_OUT<5>	
VSTM_2	F7	CUMULUS_TO_SAGE_VSTM_OUT<16>	
VSTM_3	E6	CUMULUS_TO_SAGE_VSTM_OUT<18>	
VSTM_4	E7	CUMULUS_TO_SAGE_VSTM_OUT<17>	
VSTM_5	F8	CUMULUS_TO_SAGE_VSTM_OUT<11>	
VSTM_6	G9	CUMULUS_TO_SAGE_VSTM_OUT<13>	
VSTM_7	D6	CUMULUS_TO_SAGE_VSTM_OUT<7>	
VSTM_8	D7	CUMULUS_TO_SAGE_VSTM_OUT<3>	
VSTM_9	D8	CUMULUS_TO_SAGE_VSTM_OUT<9>	
VSTM_10	F9	CUMULUS_TO_SAGE_VSTM_OUT<10>	
VSTM_11	D5	CUMULUS_TO_SAGE_VSTM_OUT<1>	
VSTM_12	F6	CUMULUS_TO_SAGE_VSTM_OUT<4>	
VSTM_13	F5	CUMULUS_TO_SAGE_VSTM_OUT<8>	
VSTM_14	G4	CUMULUS_TO_SAGE_VSTM_OUT<12>	
VSTM_15	E8	CUMULUS_TO_SAGE_VSTM_OUT<0>	
VSTM_16	G8	CUMULUS_TO_SAGE_VSTM_OUT<15>	
VSTM_17	G7	CUMULUS_TO_SAGE_VSTM_OUT<19>	
VSTM_18	G6	CUMULUS_TO_SAGE_VSTM_OUT<14>	
VSTM_19	G5	CUMULUS_TO_SAGE_VSTM_OUT<6>	
GPIO_1/CK	G1	NOTE: LCM_TO_AP_HIFA_BSYNC_BUFF	
GPIO_2/SD	D4	CUMULUS_TO_SAGE_BOOST_EN	
GPIO_3	F2	U12_GPIO_3	
GPIO_4	F3	CUMULUS_TO_SAGE_GCM_SEL	
TM_ACS*	C2	CUMULUS_TO_PROX_RX_EN_1V8	
TM_OVR	G3		

R79 100K 5% 1/32W MF 01005

PP7 P4MM SM
PP8 P4MM SM
PP9 P4MM SM ROOM=CUMULUS

AP_TO_TOUCH_SPI1_CS_L	E4	H_CS*	
TOUCH_TO_AP_INT_L	F1	H_INT*	
AP_TO_TOUCH_SPI1_CLK	D3	H_SCLK	
AP_TO_TOUCH_SPI1_MOSI	D2	H_SDI	
TOUCH_TO_AP_SPI1_MISO	E1	H_SDO	
	C4	JTAG_TCK	
	C3	JTAG_TDI	
	E2	JTAG_TDO	
	C6	JTAG_TMS	
CUMULUS_TO_PROX_TX_EN_1V8_L	E3	BCFG_RTCK	
45_AP_TO_TOUCH_CLK32K_RESET_L_XW	D1	CLKIN/RESET*	
AP_TO_TOUCH_GRAPE_RESET_L	D9	RSTOVR*	

R136 10.2 1% 1/32W MF 01005 ROOM=CUMULUS
R51 0.00 01005 ROOM=CUMULUS
(ALSO A RESET IF CLOCK STOPS) WIRED UP BY DEFAULT
TO BE USED AS TP RDAR://12608163

GND
C7 C9 G2

TOUCH B2B

J4 ROOM=TOUCH_B2B
ON MLB ---> 516S1061 PLUG
516S1060 RCPT (ON FLEX)
504459-4210 M-ST-SM

C5	TOUCH_TO_SAGE_SENSE_IN<5>	1	2	TOUCH_TO_SAGE_SENSE_IN<6>	C6
C4	TOUCH_TO_SAGE_SENSE_IN<4>	3	4	TOUCH_TO_SAGE_SENSE_IN<13>	GS3
C0	TOUCH_TO_SAGE_SENSE_IN<0>	5	6	TOUCH_TO_SAGE_SENSE_IN<7>	C7
C3	TOUCH_TO_SAGE_SENSE_IN<3>	7	8	SAGE_TO_TOUCH_VCPH_REF_CONN	VGH_REF
GS1	TOUCH_TO_SAGE_SENSE_IN<11>	9	10	SAGE_TO_TOUCH_VCPL_REF_CONN	VGL_REF
C2	TOUCH_TO_SAGE_SENSE_IN<2>	11	12	TOUCH_TO_SAGE_VCM_IN_CONN	VCOM
C1	TOUCH_TO_SAGE_SENSE_IN<1>	13	14	TOUCH_TO_SAGE_SENSE_IN<12>	GS2
GS0	TOUCH_TO_SAGE_SENSE_IN<10>	15	16	TOUCH_TO_SAGE_SENSE_IN<9>	C9
VGL	PP_SAGE_TO_TOUCH_VCPL_CONN	17	18	TOUCH_TO_SAGE_SENSE_IN<8>	C8
VGH	PP_SAGE_TO_TOUCH_VCPH_CONN	19	20	TOUCH_TO_SAGE_SENSE_IN<14>	GS4
R10	SAGE_TO_TOUCH_VSTM_OUT<10>	21	22		
R7	SAGE_TO_TOUCH_VSTM_OUT<7>	23	24	SAGE_TO_TOUCH_VSTM_OUT<17>	R17
R1	SAGE_TO_TOUCH_VSTM_OUT<1>	25	26	SAGE_TO_TOUCH_VSTM_OUT<16>	R16
R5	SAGE_TO_TOUCH_VSTM_OUT<5>	27	28	SAGE_TO_TOUCH_VSTM_OUT<15>	R15
R6	SAGE_TO_TOUCH_VSTM_OUT<6>	29	30	SAGE_TO_TOUCH_VSTM_OUT<14>	R14
R8	SAGE_TO_TOUCH_VSTM_OUT<8>	31	32	SAGE_TO_TOUCH_VSTM_OUT<13>	R13
R9	SAGE_TO_TOUCH_VSTM_OUT<9>	33	34	SAGE_TO_TOUCH_VSTM_OUT<12>	R12
R4	SAGE_TO_TOUCH_VSTM_OUT<4>	35	36	SAGE_TO_TOUCH_VSTM_OUT<11>	R11
R3	SAGE_TO_TOUCH_VSTM_OUT<3>	37	38	SAGE_TO_TOUCH_VSTM_OUT<0>	R0_RIGHT
R2	SAGE_TO_TOUCH_VSTM_OUT<2>	39	40	SAGE_TO_TOUCH_VSTM_OUT<18>	R18
R0_LEFT	SAGE_TO_TOUCH_VSTM_OUT<0>	41	42	SAGE_TO_TOUCH_VSTM_OUT<19>	R19

43 44

R47 0.00 0% 1/32W MF 01005 ROOM=TOUCH_B2B
SAGE_TO_TOUCH_VCPH_REF_CONN — SAGE_TO_TOUCH_VCPH_REF
R48 0.00 0% 1/32W MF 01005 ROOM=TOUCH_B2B
SAGE_TO_TOUCH_VCPL_REF_CONN — SAGE_TO_TOUCH_VCPL_REF
R49 0.00 0% 1/32W MF 01005 ROOM=TOUCH_B2B
TOUCH_TO_SAGE_VCM_IN_CONN — TOUCH_TO_SAGE_VCM_IN
R61 0.00 0% 1/32W MF 01005 ROOM=TOUCH_B2B
PP_SAGE_TO_TOUCH_VCPL_CONN — PP_SAGE_TO_TOUCH_VCPL
R62 0.00 0% 1/32W MF 01005 ROOM=TOUCH_B2B
PP_SAGE_TO_TOUCH_VCPH_CONN — PP_SAGE_TO_TOUCH_VCPH

SAGE_VBIAS_DRAIN
Q6 RV1C002UN SM ROOM=SAGE
SAGE_DUMP_GATE
R121 1.00M 5% 1/32W MF 01005 ROOM=SAGE
C366 0.1UF 10% 16V X5R-CERM 0201 ROOM=SAGE

THESE ARE ROUTED TOGETHER
SPECIAL - CANNOT SWAP
SPECIAL - CANNOT SWAP

XW37 SM
D2 SM-201 DSF01S30SC NOSTUFF

SAGE_VBIAS
SAGE_TO_TOUCH_VCPH_REF
SAGE_TO_TOUCH_VCPL_REF
C150 0.01UF 10% 6.3V X5R 01005 ROOM=SAGE
C147 0.01UF 10% 6.3V X5R 01005 ROOM=SAGE
C137 0.1UF 10% 6.3V X5R 201 ROOM=SAGE

R36 100K 5% 1/32W MF 01005
LCM_TO_AP_HIFA_BSYNC_BUFF
CUMULUS_TO_PROX_TX_EN_BUFF

U5 74AUP2G3404GN SOT1115 VCC GND
LCM_TO_AP_HIFA_BSYNC
CUMULUS_TO_PROX_TX_EN_1V8_L

R2 100K 5% 1/32W MF 01005

C321 0.33UF 20% 10V TANT 0402 ROOM=SAGE
C328 1000PF 10% 25V X7R-CERM 0201 ROOM=SAGE
C349 1000PF 10% 25V X7R-CERM 0201 ROOM=SAGE
C320 1UF 20% 25V TANT 0603-LLP ROOM=SAGE
C346 1000PF 10% 25V X7R-CERM 0201 ROOM=SAGE
C364 1000PF 10% 25V X7R-CERM 0201 ROOM=SAGE

L21 10UH-0.32A-1.56OHM PSB121201T-SM ROOM=SAGE

C149 10UF 20% 10V X5R-CERM 0402-1 ROOM=SAGE
DZ4 GDZT2R6.2B 0DZ-0201 ROOM=SAGE
TO CLAMP THE NEGATIVE RAIL
C156 10UF 20% 10V X5R-CERM 0402-1 ROOM=SAGE OMIT_TABLE
C170 0.1UF 10% 16V X5R-CERM 0201 ROOM=SAGE
C365 0.1UF 10% 16V X5R-CERM 0201 ROOM=SAGE

SAGE_PANEL_IN IS SENSITIVE
KEEP THESE NETS FROM XTALK

TOUCH_TO_SAGE_SENSE_IN<4>	E4	SNS_IN0	
TOUCH_TO_SAGE_SENSE_IN<3>	D4	SNS_IN1	
TOUCH_TO_SAGE_SENSE_IN<5>	C4	SNS_IN2	
TOUCH_TO_SAGE_SENSE_IN<0>	B4	SNS_IN3	
TOUCH_TO_SAGE_SENSE_IN<12>	A4	SNS_IN4	
TOUCH_TO_SAGE_SENSE_IN<7>	A6	SNS_IN5	
TOUCH_TO_SAGE_SENSE_IN<10>	B6	SNS_IN6	
TOUCH_TO_SAGE_SENSE_IN<1>	C6	SNS_IN7	
TOUCH_TO_SAGE_SENSE_IN<11>	D6	SNS_IN8	
TOUCH_TO_SAGE_SENSE_IN<2>	E6	SNS_IN9	
TOUCH_TO_SAGE_SENSE_IN<13>	E8	SNS_IN10	
TOUCH_TO_SAGE_SENSE_IN<14>	D8	SNS_IN11	
TOUCH_TO_SAGE_SENSE_IN<8>	C8	SNS_IN12	
TOUCH_TO_SAGE_SENSE_IN<9>	B8	SNS_IN13	
TOUCH_TO_SAGE_SENSE_IN<6>	A8	SNS_IN14	

CUMULUS_TO_SAGE_VSTM_OUT<8>	G1	DRV_IN0	
CUMULUS_TO_SAGE_VSTM_OUT<6>	H1	DRV_IN1	
CUMULUS_TO_SAGE_VSTM_OUT<12>	J1	DRV_IN2	
CUMULUS_TO_SAGE_VSTM_OUT<1>	K1	DRV_IN3	
CUMULUS_TO_SAGE_VSTM_OUT<7>	L1	DRV_IN4	
CUMULUS_TO_SAGE_VSTM_OUT<15>	G2	DRV_IN5	
CUMULUS_TO_SAGE_VSTM_OUT<14>	H2	DRV_IN6	
CUMULUS_TO_SAGE_VSTM_OUT<18>	J2	DRV_IN7	
CUMULUS_TO_SAGE_VSTM_OUT<5>	K2	DRV_IN8	
	L2	DRV_IN9	
CUMULUS_TO_SAGE_VSTM_OUT<4>	K3	DRV_IN10	
CUMULUS_TO_SAGE_VSTM_OUT<19>	J3	DRV_IN11	
CUMULUS_TO_SAGE_VSTM_OUT<13>	H3	DRV_IN12	
CUMULUS_TO_SAGE_VSTM_OUT<16>	G3	DRV_IN13	
CUMULUS_TO_SAGE_VSTM_OUT<3>	L4	DRV_IN14	
CUMULUS_TO_SAGE_VSTM_OUT<2>	K4	DRV_IN15	
CUMULUS_TO_SAGE_VSTM_OUT<0>	J4	DRV_IN16	
CUMULUS_TO_SAGE_VSTM_OUT<11>	H4	DRV_IN17	
CUMULUS_TO_SAGE_VSTM_OUT<17>	G4	DRV_IN18	
	D3	DRV_IN19	

U15 SAGE2-B06 CSP

VBIAS	D3		
VCPH_REF/EN	A2		
VCPL_REF/EN	F2		
VBST_OUTH	B1		
VBST_OUTL	E1		
L_X	C1		
L_Y	D1		
AVDDH1	D2		
AVDDH2	A3		
AVDDH3	F3		
AVDDH4	F6		
AVDDL1	H5		
VCPH	A1		
VCPL	F1		
VCPL_F	E2		
VDDIO	C3		
AGND1	B3		
AGND2	E4		
AGND3	F4		
AGND4	F8		
AGND5	E3		
AGND6	L5		
BSYNC	K5	LCM_TO_AP_HIFA_BSYNC	
GCM_TEST	F9	CUMULUS_TO_SAGE_GCM_SEL	
GO	F7		
VCM_IN	J5	TOUCH_TO_SAGE_VCM_IN	
I2C_SCL	F5		
I2C_SDA	G5		
BOOST_EN	B2	CUMULUS_TO_SAGE_BOOST_EN	

CUMULUS_IN IS SENSITIVE
KEEP THESE NETS FROM XTALK

SNS_OUT0	E5	SAGE_TO_CUMULUS_IN<4>	
SNS_OUT1	D5	SAGE_TO_CUMULUS_IN<3>	
SNS_OUT2	C5	SAGE_TO_CUMULUS_IN<5>	
SNS_OUT3	B5	SAGE_TO_CUMULUS_IN<0>	
SNS_OUT4	A5	SAGE_TO_CUMULUS_IN<12>	
SNS_OUT5	A7	SAGE_TO_CUMULUS_IN<7>	
SNS_OUT6	B7	SAGE_TO_CUMULUS_IN<10>	
SNS_OUT7	C7	SAGE_TO_CUMULUS_IN<1>	
SNS_OUT8	D7	SAGE_TO_CUMULUS_IN<11>	
SNS_OUT9	E7	SAGE_TO_CUMULUS_IN<2>	
SNS_OUT10	E9	SAGE_TO_CUMULUS_IN<13>	
SNS_OUT11	D9	SAGE_TO_CUMULUS_IN<14>	
SNS_OUT12	C9	SAGE_TO_CUMULUS_IN<8>	
SNS_OUT13	B9	SAGE_TO_CUMULUS_IN<9>	
SNS_OUT14	A9	SAGE_TO_CUMULUS_IN<6>	

DRV_OUT0	G6	SAGE_TO_TOUCH_VSTM_OUT<8>	
DRV_OUT1	H6	SAGE_TO_TOUCH_VSTM_OUT<6>	
DRV_OUT2	J6	SAGE_TO_TOUCH_VSTM_OUT<12>	
DRV_OUT3	K6	SAGE_TO_TOUCH_VSTM_OUT<1>	
DRV_OUT4	L6	SAGE_TO_TOUCH_VSTM_OUT<7>	
DRV_OUT5	G7	SAGE_TO_TOUCH_VSTM_OUT<15>	
DRV_OUT6	H7	SAGE_TO_TOUCH_VSTM_OUT<14>	
DRV_OUT7	J7	SAGE_TO_TOUCH_VSTM_OUT<18>	
DRV_OUT8	K7	SAGE_TO_TOUCH_VSTM_OUT<5>	
DRV_OUT9	L7	SAGE_TO_TOUCH_VSTM_OUT<9>	
DRV_OUT10	L8	SAGE_TO_TOUCH_VSTM_OUT<10>	
DRV_OUT11	K8	SAGE_TO_TOUCH_VSTM_OUT<4>	
DRV_OUT12	J8	SAGE_TO_TOUCH_VSTM_OUT<19>	
DRV_OUT13	H8	SAGE_TO_TOUCH_VSTM_OUT<13>	
DRV_OUT14	G8	SAGE_TO_TOUCH_VSTM_OUT<16>	
DRV_OUT15	L9	SAGE_TO_TOUCH_VSTM_OUT<3>	
DRV_OUT16	K9	SAGE_TO_TOUCH_VSTM_OUT<2>	
DRV_OUT17	J9	SAGE_TO_TOUCH_VSTM_OUT<0>	
DRV_OUT18	H9	SAGE_TO_TOUCH_VSTM_OUT<11>	
DRV_OUT19	G9	SAGE_TO_TOUCH_VSTM_OUT<17>	

C163 0.1UF 10% 6.3V X5R 201 ROOM=SAGE
C165 0.1UF 20% 6.3V X5R-CERM 01005 ROOM=SAGE
PP11 P4MM SM ROOM=SAGE
PP18 P4MM NSM ROOM=SAGE

SAGE2 B06
343S0628

www.vinafix.vn

LCM B2B

LCM:
2-LANE MIPI

TO DO: R89 CANDIDATE FOR REMOVAL
DRI: LCD/TOUCH TEAM. KEEP AS OF 5/30/12

R89 0.00 5% 1/32W MF 01005 ROOM=LCM_B2B
24 18 PP_SAGE_TO_TOUCH_VCPL
SAGE_TO_TOUCH_VCPL_LCM_CONN

L41 90-OHM-50MA TCM0605-1 SYM_VER-2 ROOM=LCM_B2B
7 90_AP_BI_LCM_MIPI_DATA0_P
7 90_AP_BI_LCM_MIPI_DATA0_N
90_AP_BI_LCM_MIPI_DATA0_CONN_P
90_AP_BI_LCM_MIPI_DATA0_CONN_N

L44 90-OHM-50MA TCM0605-1 SYM_VER-2 ROOM=LCM_B2B
7 90_AP_TO_LCM_MIPI_DATA1_P
7 90_AP_TO_LCM_MIPI_DATA1_N
90_AP_TO_LCM_MIPI_DATA1_CONN_P
90_AP_TO_LCM_MIPI_DATA1_CONN_N

L42 90-OHM-50MA TCM0605-1 SYM_VER-2 ROOM=LCM_B2B
7 90_AP_TO_LCM_MIPI_CLK_P
7 90_AP_TO_LCM_MIPI_CLK_N
90_AP_TO_LCM_MIPI_CLK_CONN_P
90_AP_TO_LCM_MIPI_CLK_CONN_N

THIS ONE ON MLB ---> 516S1051 PLUG
516S1050 RCPT (FLEX)

ROOM=LCM_B2B J5 BM15AP-0.8-22DP-0.35V M-ST-SM

1	PN5V7_LCM_AVDDN	
2	PP5V7_LCM_AVDDH_CONN	3
3	PP1V8_LCM_CONN	3
4	LCM_TO_CHESTNUT_PWR_EN_CONN	
5	AP_TO_LCM_RESET_CONN_L	
6	LCM_TO_AP_HIFA_BSYNC_CONN	
7	LCM_TO_AP_PANIC_L	
8	LCM_TO_AP_PIFA_CONN	
9	PP_LCM_BL_ANODE_CONN	22
10	PP_LCM_BL_CAT1_CONN	22
11	PP_LCM_BL_CAT2_CONN	22

FL61 70-OHM-300MA 01005-1 ROOM=LCM_B2B
PN5V7_SAGE_AVDDN 14 18

C444 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B
0.450MOHM DCR
FL37 80-OHM-0.2A-0.4-OHM 0201-1 ROOM=LCM_B2B 0.460MOHM DCR
PP5V7_LCM_AVDDH 14 24

C94 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B
C350 4.7UF 20% 6.3V X5R 402 ROOM=LCM_B2B
C351 4.7UF 20% 6.3V X5R 402 ROOM=LCM_B2B
SPECIAL Z = 0.60 MM
FL27 80-OHM-0.2A-0.4-OHM 0201-1 ROOM=LCM_B2B 0.460MOHM DCR
PP1V8 2 3 5 6 7 10 11 12 14 16 18 19 21 24

C440 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B
C439 0.1UF 10% 6.3V X5R 201 ROOM=LCM_B2B

LCM:
POWER
(1.8V DVDD)
(+5.7V AVDD)
(-5.7V AVDD)

FL35 120-OHM-210MA 01005 ROOM=LCM_B2B
LCM_TO_CHESTNUT_PWR_EN 13 14

C93 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B
R91 100K 5% 1/32W MF 01005 ROOM=LCM_B2B NOSTUFF
TO DO: REMOVE R91 AFTER PROTO2.
CHESTNUT HAS 200K INT PD ON THIS PIN.
NOSTUFF FOR PROTO2

ADD RDAR://12334944
R24 100K 1% 1/32W MF 01005 ROOM=LCM_B2B NOSTUFF
PP1V8

FL36 120-OHM-210MA 01005 ROOM=LCM_B2B
AP_TO_LCM_RESET_L 3

R152 100K 1% 1/32W MF 01005 ROOM=LCM_B2B
C90 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B
R14 0.00 5% 1/32W MF 01005 ROOM=LCM_B2B NOSTUFF
PMU_TO_LCM_RESET_L
ADD RDAR://12334944

FL34 120-OHM-210MA 01005 ROOM=LCM_B2B
LCM_TO_AP_HIFA_BSYNC 3 18

C88 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B
PP1V8 2 3 5 6 7 10 11 12 14 16 18 19 21 24

R46 100K 5% 1/32W MF 01005 ROOM=LCM_B2B
FL62 150OHM-25%-200MA-0.7DCR 01005 ROOM=LCM_B2B NOSTUFF
RESET_1V8_L 2 4 13 14 16 22 23

C295 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B

R60 1.00K 5% 1/32W MF 01005 ROOM=LCM_B2B NOSTUFF
LCM_TO_AP_PIFA 3

C258 56PF 5% 6.3V NP0-C0G 01005 ROOM=LCM_B2B

LCM:
DIGITAL I/F
(PWR_EN, RESET
PIFA, BSYNC)

FL24 240-OHM-0.2A-0.8-OHM 0201-1 ROOM=LCM_B2B
PP_LCM_BL_ANODE 14 24

C17 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B
LCM_DESENSE_CONN
C243 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B

FL25 240-OHM-0.2A-0.8-OHM 0201-1 ROOM=LCM_B2B
PP_LCM_BL_CAT1 14 24

C18 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B

FL26 240-OHM-0.2A-0.8-OHM 0201-1 ROOM=LCM_B2B
PP_LCM_BL_CAT2 14 24

C19 56PF 5% 16V NP0-C0G 01005 ROOM=LCM_B2B

LCM:
BACKLIGHT

PCB: ALL 56PF CAPS GO AT CONN

www.vinafix.vn

OSCAR + SENSORS

OSCAR MODULE (CONFORMAL COATED)

APN 337S4417



OSCAR MODULE GND BALLS

(THIS SYMBOL DOES NOT EXIST ON OSCAR CSP)

THESE PARTS INSIDE OF SHIELD

GYRO

X152: INVENSENSE ITG-3600, APN 338S1135



ACCELEROMETER

X152: BOSCH BMA282, APN 338S1163



THIS PART OUTSIDE OF SHIELD

COMPASS

COMPASS CSP: 338S1014
COMPASS INTERPOSER (FOOTPRINT ONLY): 998-5120
COMPASS INTERPOSER MODULE: 639-4269



www.vinafix.vn

RCAM B2B (REAR CAMERA CONNECTOR)

RCAM:
POWER:
(1.8V DVDD)
(2.8V AVDD)
(1.2V VCC)
(2.5V AF)

RCAM:
DIGITAL I/F
(I2C,CTRL,CLK)

RCAM:
4-LANE MIPI

PP2V5_RCAM_AF_COMP

L29
FERR-22-OHM-1A-0.065-OHM
PP2V5_RCAM_AF
0201
C423 1.0UF 20% 6.3V X5R 0201-1
C391 1.0UF 20% 6.3V X5R 0201-1
C393 56PF 5% 6.3V NP0-C0G 01005

1.2V RCAM LOAD SWITCH
U13
TPS22924X
CSP
PP1V2_SDRAM
VIN
VOUT
ON
GND
PP1V2_RCAM_SWITCHOUT
C390 1.0UF 20% 6.3V X5R 0201-1
C389 1.0UF 20% 6.3V X5R 0201-1
C392 56PF 5% 6.3V NP0-C0G 01005
AP_TO_RCAM_VDDCORE_EN
R169 510K 5% 1/32W MF 01005
L30
FERR-22-OHM-1A-0.065-OHM
0201

L28
FERR-22-OHM-1A-0.065-OHM
PP1V8
0201
C395 56PF 5% 6.3V NP0-C0G 01005

PP2V85_CAM_AVDD
XW46
SHORT-10L-0.1MM-SM
45_CAM_AVDD_FB
PCB: PLACE THIS XW AT C193.1
FL43
10-OHM-750MA
01005-1
0.07 OHMS
C193 10UF 20% 6.3V X5R 0603
C2511 4.7UF 20% 6.3V X5R 402
C249 2.2UF 20% 4V X5R-CERM 0201
C403 2.2UF 20% 4V X5R-CERM 0201
C404 56PF 5% 6.3V NP0-C0G 01005

FL29
120-OHM-210MA
AP_BI_RCAM_I2C_SDA
FL31
120-OHM-210MA
AP_TO_RCAM_I2C_SCL
C287 56PF 5% 6.3V NP0-C0G 01005
C286 56PF 5% 6.3V NP0-C0G 01005
FL30
120-OHM-210MA
AP_TO_RCAM_SHUTDOWN
R141 100K 5% 1/32W MF 01005
FL28
120-OHM-210MA
45_AP_TO_RCAM_CLK
C82 56PF 5% 6.3V NP0-C0G 01005
C84 56PF 5% 6.3V NP0-C0G 01005
FL22
120-OHM-210MA
RCAM_TO_LEDDRV_STROBE_EN
C400 56PF 5% 6.3V NP0-C0G 01005
PCB: PLACE ALL 56PF CAPS AT J3

THIS ONE ON MLB ---> 516S0940 PLUG
516S0939 RCPT (USED ON FLEX)
XW31
SM
J3
BB35-PA
M-ST-SM

PGND_RCAM_AF_RET
PP2V5_RCAM_AF_CONN
AP_BI_RCAM_I2C_SDA_CONN
AP_TO_RCAM_I2C_SCL_CONN
PP1V2_RCAM_CONN
PP1V8_RCAM_CONN
AP_TO_RCAM_SHUTDOWN_CONN
45_AP_TO_RCAM_CLK_CONN
RCAM_TO_LEDDRV_STROBE_EN_CONN
PP2V85_RCAM_CONN

90_RCAM_TO_AP_MIPI_DATA3_CONN_P
90_RCAM_TO_AP_MIPI_DATA3_CONN_N
90_RCAM_TO_AP_MIPI_DATA2_CONN_P
90_RCAM_TO_AP_MIPI_DATA2_CONN_N
90_RCAM_TO_AP_MIPI_CLK_CONN_P
90_RCAM_TO_AP_MIPI_CLK_CONN_N
90_RCAM_TO_AP_MIPI_DATA1_CONN_P
90_RCAM_TO_AP_MIPI_DATA1_CONN_N
90_RCAM_TO_AP_MIPI_DATA0_CONN_P
90_RCAM_TO_AP_MIPI_DATA0_CONN_N

L34 90-OHM-50MA TCM0605-1
L33 90-OHM-50MA TCM0605-1
L37 90-OHM-50MA TCM0605-1
L38 90-OHM-50MA TCM0605-1
L36 90-OHM-50MA TCM0605-1

90_RCAM_TO_AP_MIPI_DATA3_P
90_RCAM_TO_AP_MIPI_DATA3_N
90_RCAM_TO_AP_MIPI_DATA2_P
90_RCAM_TO_AP_MIPI_DATA2_N
90_RCAM_TO_AP_MIPI_CLK_P
90_RCAM_TO_AP_MIPI_CLK_N
90_RCAM_TO_AP_MIPI_DATA1_P
90_RCAM_TO_AP_MIPI_DATA1_N
90_RCAM_TO_AP_MIPI_DATA0_P
90_RCAM_TO_AP_MIPI_DATA0_N

www.vinafix.vn

BATT CONN, TPS, STANDOFFS/SHIELDS/FIDUCIALS

BATTERY CONN



FIDUCIALS



SHIELDS



COWLING



AC COUPLED SCREW HOLES + STANDOFFS

(ON NORTH END OF SINGLE_BRD, TO MITIGATE COMPASS RETURN CURRENTS)

SCREW HOLES



STANDOFFS



TESTPOINTS

POWER TP

- PP5V0_USB_CONN → TP1 (TP-P6) — VBUS
- TP2 (TP-P90) — POWER GROUND (SUPERSIZE)
- PP_BATT_VCC → TP12 (TP-P80) — VBAT (SUPERSIZE)

SUPER TP

- BATTERY_TO_PMU_SENSE → TP4 (TP-P6) — BATTERY SNS
- BATTERY_TO_PMU_NTC → TP5 (TP-P6) — BATTERY NTC
- PMU_TO_TP_AMUX_AY → TP6 (TP-P6) — ANALOG MUX A OUTPUT
- PMU_TO_TP_AMUX_BY → TP7 (TP-P6) — ANALOG MUX B OUTPUT

RESET

- RESET_1V8_L → TP8000 (TP-P6) — H6P & BB RESET

DFU

- FORCE_DFU → TP9 (TP-P6) — FORCE DFU

HEADPHONE MIC

- CODEC_TO_HPHONE_HS3_REF → TP28 (TP-P6) — HEADPHONE MIC NEG
- CODEC_TO_HPHONE_HS4_REF → TP29 (TP-P6) — HEADPHONE MIC POS

LCM BACKLIGHT

- PP_LCM_BL_CAT1_CONN → TP18 (TP-P6) — LCD BACKLIGHT SINK1
- PP_LCM_BL_CAT2_CONN → TP19 (TP-P6) — LCD BACKLIGHT SINK2
- PP_LCM_BL_ANODE_CONN → TP20 (TP-P6) — LCD BACKLIGHT SOURCE

E75 - USB/UART/ID/POWER

- 90_TRISTAR_BI_E75_PAIR1_P → TP21 (TP-P55)
- 90_TRISTAR_BI_E75_PAIR1_N → TP22 (TP-P55)
- 90_TRISTAR_BI_E75_PAIR2_P → TP23 (TP-P55)
- 90_TRISTAR_BI_E75_PAIR2_N → TP24 (TP-P55)
- PP_E75_TO_TRISTAR_ACC1_CONN → TP26 (TP-P6)
- PP_E75_TO_TRISTAR_ACC2_CONN → TP27 (TP-P6)

ACCESSORY ID AND POWER

- TP32 (TP-P6) — POWER GROUND
- E75_TO_PMU_ACC_DETECT_CONN → TP10 (TP-P6) — FOR DIAGS

MIC AUDIO

- MIC1_TO_CODEC_P → TP15 (TP-P6) — MIC1 POSITIVE
- MIC2_TO_CODEC_P → TP16 (TP-P6) — MIC2 POSITIVE
- MIC3_TO_CODEC_P → TP17 (TP-P6) — MIC3 POSITIVE

DRIVE MIC WRT NEAREST GROUND TEST POINT

- SPKAMP_TO_SPEAKER_OUT_CONN_P → TP3 (TP-P6) — SPKR POSITIVE (ADDED PER RDAR://12460740)
- SPKAMP_TO_SPEAKER_OUT_CONN_N → TP11 (TP-P6) — SPKR NEGATIVE

www.vinafix.vn

VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<0>	VOLTAGE=3.8V	CODEC_TO_RCVR_P	VOLTAGE=2.5V	BATTERY_TO_PMU_NTC	VOLTAGE=1.8V	PP1V8
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<1>	VOLTAGE=3.8V	CODEC_TO_RCVR_N	VOLTAGE=2.5V	BATTERY_NTC_CONN	VOLTAGE=1.8V	PP1V8_ALWAYS
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<2>	VOLTAGE=3.8V	CODEC_TO_RCVR_CONN_P	VOLTAGE=4.2V	BATTERY_TO_PMU_SENSE	VOLTAGE=1.8V	PP1V8_COMP
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<3>	VOLTAGE=3.8V	CODEC_TO_RCVR_CONN_N	VOLTAGE=18V	MESA_BOOST_FB	VOLTAGE=1.8V	PP1V8_CUMULUS_VDDLDO
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<4>	VOLTAGE=3.8V	CODEC_TO_HAC_P	VOLTAGE=8V	SPEAKER_TO_SPKAMP_VSENSE_P	VOLTAGE=1.8V	PP1V8_FCAM_CONN
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<5>	VOLTAGE=3.8V	CODEC_TO_HAC_N	VOLTAGE=8V	SPEAKER_TO_SPKAMP_VSENSE_N	VOLTAGE=1.8V	PP1V8_GRAPE
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<6>	VOLTAGE=3.8V	CODEC_TO_HAC_CONN_P	VOLTAGE=8V	L19_SPKAMP_VSENSE_P	VOLTAGE=1.8V	PP1V8_LCM_CONN
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<7>	VOLTAGE=3.8V	CODEC_TO_HAC_CONN_N	VOLTAGE=8V	L19_SPKAMP_VSENSE_N	VOLTAGE=1.8V	PP1V8_OSCAR
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<8>	VOLTAGE=3.114V	CODEC_TO_HPHONE_L	VOLTAGE=8V	SPEAKER_TO_SPKAMP_ISENSE_P	VOLTAGE=1.8V	PP1V8_OSCAR_VDDIO
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<9>	VOLTAGE=3.114V	CODEC_TO_HPHONE_R	VOLTAGE=8V	SPEAKER_TO_SPKAMP_ISENSE_N	VOLTAGE=1.8V	PP1V8_PLL
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<10>	VOLTAGE=3.114V	CODEC_TO_HPHONE_L_CONN	VOLTAGE=8V	SPKR_SNS_P	VOLTAGE=1.8V	PP1V8_RCAM_CONN
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<11>	VOLTAGE=3.114V	CODEC_TO_HPHONE_R_CONN	VOLTAGE=8V	SPKR_SNS_N	VOLTAGE=1.8V	PP1V8_SDRAM
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<12>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS3	VOLTAGE=8V	SPKR_FLTR_P	VOLTAGE=1.8V	PP1V8_SDRAM_DOCK_CONN
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<13>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS4	VOLTAGE=8V	SPKAMP_TO_SPEAKER_OUT_CONN_P	VOLTAGE=1.8V	PP1V8_VA_L19_L67
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<14>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS3_REF	VOLTAGE=8V	SPKAMP_TO_SPEAKER_OUT_CONN_N	VOLTAGE=1.8V	PP1V8_XTAL
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<15>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS4_REF	VOLTAGE=8V	SPKAMP_TO_SPEAKER_OUT_P	VOLTAGE=2.5V	PP2V5_RCAM_AF
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<16>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS3_CONN	VOLTAGE=8V	SPKAMP_TO_SPEAKER_OUT_N	VOLTAGE=2.5V	PP2V5_RCAM_AF_COMP
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<17>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS4_CONN	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR1_P	VOLTAGE=2.5V	PP2V5_RCAM_AF_CONN
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<18>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS3_REF_CONN	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR1_N	VOLTAGE=2.8V	PP2V85_CAM_AVDD
VOLTAGE=4.55V	CUMULUS_TO_SAGE_VSTM_OUT<19>	VOLTAGE=2.7V	CODEC_TO_HPHONE_HS4_REF_CONN	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR2_P	VOLTAGE=2.8V	PP2V85_FCAM_CONN
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<0>	VOLTAGE=4.3V	HPHONE_TO_CODEC_DET	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR2_N	VOLTAGE=2.8V	PP2V85_RCAM_CONN
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<1>	VOLTAGE=4.3V	HPHONE_TO_CODEC_DET_CONN	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR1_CONN_P	VOLTAGE=3.0V	PP3V0_ACC
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<2>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_L67_P	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR1_CONN_N	VOLTAGE=3.0V	PP3V0_ALS
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<3>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_L67_N	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR2_CONN_P	VOLTAGE=3.0V	PP3V0_COMP
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<4>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_P	VOLTAGE=5.25V	90_TRISTAR_BI_E75_PAIR2_CONN_N	VOLTAGE=3.0V	PP3V0_IMU
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<5>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_N	VOLTAGE=3.0V	TRISTAR_BYPASS	VOLTAGE=3.0V	PP3V0_NAND
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<6>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_DIG_P	VOLTAGE=-5.7V	PN5V7_SAGE_AVDDN	VOLTAGE=3.0V	PP3V0_NAND_XW
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<7>	VOLTAGE=2.5V	90_CODEC_BI_TRISTAR_MIKEYBUS_DIG_N	VOLTAGE=-5.7V	PN5V7_LCM_AVDDN	VOLTAGE=3.0V	PP3V0_NAVAJO
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<8>	VOLTAGE=2.5V	TRISTAR_TO_PMU_MIKEYBUS_TEST_POS	VOLTAGE=-5.7V	SAGE_DUMP_GATE	VOLTAGE=3.0V	PP3V0_NAVAJO_CONN
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<9>	VOLTAGE=2.5V	TRISTAR_TO_PMU_MIKEYBUS_TEST_NEG	VOLTAGE=2.5V	SAGE_VBIAS	VOLTAGE=3.0V	PP3V0_PROX
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<10>	VOLTAGE=1.8V	MIC1_TO_CODEC_L67_P	VOLTAGE=2.5V	SAGE_VBIAS_DRAIN	VOLTAGE=3.0V	PP3V0_PROX_ALS
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<11>	VOLTAGE=1.8V	MIC1_TO_CODEC_L67_N	VOLTAGE=-12V	SAGE_TO_TOUCH_VCPL_LCM_CONN	VOLTAGE=3.0V	PP3V0_PROX_IRLED
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<12>	VOLTAGE=1.8V	MIC1_TO_CODEC_P	VOLTAGE=11V	GYRO_PUMP	VOLTAGE=3.0V	PP3V0_SDRAM
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<13>	VOLTAGE=1.8V	MIC1_TO_CODEC_N	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<0>	VOLTAGE=3.0V	PP3V0_SDRAM_CONN
VOLTAGE=4.55V	TOUCH_TO_SAGE_SENSE_IN<14>	VOLTAGE=1.8V	MIC2_TO_CODEC_L67_P	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<1>	VOLTAGE=3.3V	PP3V3_USB
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<0>	VOLTAGE=1.8V	MIC2_TO_CODEC_L67_N	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<2>	VOLTAGE=5.0V	PP5V0_USB_CONN
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<1>	VOLTAGE=1.8V	MIC2_TO_CODEC_P	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<3>	VOLTAGE=5.0V	PP5V0_USB_PROT
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<2>	VOLTAGE=1.8V	MIC2_TO_CODEC_N	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<4>	VOLTAGE=5.1V	PP5V1_GRAPE_VDDH
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<3>	VOLTAGE=1.8V	MIC3_TO_CODEC_L67_P	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<5>	VOLTAGE=5.7V	PP5V7_LCM_AVDDH
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<4>	VOLTAGE=1.8V	MIC3_TO_CODEC_L67_N	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<6>	VOLTAGE=5.7V	PP5V7_LCM_AVDDH_CONN
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<5>	VOLTAGE=1.8V	MIC3_TO_CODEC_P	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<7>	VOLTAGE=5.7V	PP5V7_SAGE_AVDDH
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<6>	VOLTAGE=1.8V	MIC3_TO_CODEC_N	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<8>	VOLTAGE=6V	PP6V0_LCM_BOOST
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<7>	VOLTAGE=3.8V	RCVR_TO_CODEC_RCVR_TEST	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<9>	VOLTAGE=4.3V	PP_BATT_VCC
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<8>	VOLTAGE=3.8V	RCVR_TO_CODEC_RCVR_TEST_L67	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<10>	VOLTAGE=4.3V	PP_BATT_VCC_L19_VP
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<9>	VOLTAGE=3.114V	HPHONE_TO_CODEC_HPHONE_TEST	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<11>	VOLTAGE=4.3V	PP_BUCK0_LX0
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<10>	VOLTAGE=3.114V	HPHONE_TO_CODEC_HPHONE_TEST_L67	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<12>	VOLTAGE=4.3V	PP_BUCK0_LX1
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<11>	VOLTAGE=3.8V	HAC_TO_CODEC_TEST	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<13>	VOLTAGE=4.3V	PP_BUCK0_LX2
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<12>	VOLTAGE=3.8V	HAC_TO_CODEC_TEST_L67	VOLTAGE=XV	SAGE_TO_CUMULUS_IN<14>	VOLTAGE=4.3V	PP_BUCK0_LX3
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<13>	VOLTAGE=2.85V	45_CAM_AVDD_FB	VOLTAGE=18.0V	PP16V5_MESA	VOLTAGE=4.3V	PP_BUCK1_LX0
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<14>	VOLTAGE=4.6V	45_PMU_VPUMP	VOLTAGE=18.0V	PP16V5_MESA_DOCK_CONN	VOLTAGE=4.3V	PP_BUCK1_LX1
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<15>	VOLTAGE=4.3V	PMU_ACT_DIO	VOLTAGE=18.0V	PP16V5_MESA_SW	VOLTAGE=4.3V	PP_BUCK2_LX
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<16>	VOLTAGE=3.6V	TRISTAR_TO_PMU_OVP_SW_EN_L	VOLTAGE=1.0V	PP1V0	VOLTAGE=4.3V	PP_BUCK3_LX
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<17>	VOLTAGE=3.2V	USB_VBUS_DETECT	VOLTAGE=1.0V	PP1V0_SOC	VOLTAGE=4.3V	PP_BUCK4_LX
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<18>	VOLTAGE=5.25V	TRISTAR_TO_PMU_USB_BRICKID	VOLTAGE=1.0V	PP1V0_SRAM	VOLTAGE=4.3V	PP_BUCK5_LX
VOLTAGE=4.55V	SAGE_TO_TOUCH_VSTM_OUT<19>	VOLTAGE=5.25V	TRISTAR_TO_PMU_USB_BRICKID_R	VOLTAGE=1.1V	PP1V1_CPU	VOLTAGE=-6V	PP_CHESTNUT_CN
				VOLTAGE=1.1V	PP1V1_GPU	VOLTAGE=6V	PP_CHESTNUT_CP
				VOLTAGE=1.2V	PP1V2	VOLTAGE=6V	PP_CHESTNUT_LXP
				VOLTAGE=1.2V	PP1V2_NAND_VDDI	VOLTAGE=1.8V	PP_CODEC_FILT+
				VOLTAGE=1.2V	PP1V2_OSCAR	VOLTAGE=2.2V	PP_CODEC_SPKR_VQ
				VOLTAGE=1.2V	PP1V2_OSCAR_VDDC	VOLTAGE=2.7V	PP_CODEC_TO_MIC1_BIAS
				VOLTAGE=1.2V	PP1V2_RCAM_CONN	VOLTAGE=2.7V	PP_CODEC_TO_MIC1_BIAS_CONN
				VOLTAGE=1.2V	PP1V2_RCAM_SWITCHOUT	VOLTAGE=2.7V	PP_CODEC_TO_MIC2_3_BIAS
				VOLTAGE=1.2V	PP1V2_SDRAM	VOLTAGE=2.7V	PP_CODEC_TO_MIC3_BIAS_CONN
						VOLTAGE=2.5V	PP_CODEC_VCPFILT+
						VOLTAGE=-2.5V	PP_CODEC_VCPFILT-

VOLTAGE=0.2V	PP_CODEC_VHP_FLYC	VOLTAGE=2.65V	PP_LDO14_2P65
VOLTAGE=-2.5V	PP_CODEC_VHP_FLYN	VOLTAGE=2.5V	CHESTNUT_TO_PMU_ADCIN7
VOLTAGE=2.5V	PP_CODEC_VHP_FLYP	VOLTAGE=5V	E75_TO_PMU_ACC_DETECT
VOLTAGE=1.6V	PP_CUMULUS_VDDANA	VOLTAGE=5V	E75_TO_PMU_ACC_DETECT_R
VOLTAGE=1.6V	PP_CUMULUS_VDDCORE	VOLTAGE=5V	PMU_TO_TP_AMUX_AY
VOLTAGE=4.3V	PP_E75_TO_TRISTAR_ACC1	VOLTAGE=5V	PMU_TO_TP_AMUX_BY
VOLTAGE=4.3V	PP_E75_TO_TRISTAR_ACC1_CONN	VOLTAGE=2.5V	FOREHEAD_TO_PMU_NTC_P
VOLTAGE=4.3V	PP_E75_TO_TRISTAR_ACC2	VOLTAGE=2.5V	CAM_TO_PMU_NTC_P
VOLTAGE=4.3V	PP_E75_TO_TRISTAR_ACC2_CONN	VOLTAGE=2.5V	PA_TO_PMU_NTC_P
VOLTAGE=2.7V	PP_EXTMIC_BIAS	VOLTAGE=2.5V	H6P_TO_PMU_NTC_P
VOLTAGE=2.7V	PP_EXTMIC_BIAS_FILT	VOLTAGE=2.5V	45_PMU_TCAL
VOLTAGE=2.7V	PP_EXTMIC_BIAS_FILT_IN	VOLTAGE=5V	PP_LED_BOOST_OUT
VOLTAGE=2.7V	PP_EXTMIC_BIAS_IN	VOLTAGE=5V	PP_LED_DRV_LX
VOLTAGE=8V	PP_L19_VBOOST	VOLTAGE=0.4V	PP_MIPI0D_VREG
VOLTAGE=22V	PP_LCM_BL_ANODE	VOLTAGE=0.4V	PP_MIPI1D_VREG
VOLTAGE=22V	PP_LCM_BL_ANODE_CONN	VOLTAGE=3.4V	PP_PMU_TO_VIBE
VOLTAGE=0.2V	PP_LCM_BL_CAT1	VOLTAGE=3.4V	PP_PMU_TO_VIBE_CONN
VOLTAGE=0.2V	PP_LCM_BL_CAT1_CONN	VOLTAGE=5.25V	PP_PMU_VCENTER
VOLTAGE=0.2V	PP_LCM_BL_CAT2	VOLTAGE=4.3V	PP_PMU_VDD_REF
VOLTAGE=0.2V	PP_LCM_BL_CAT2_CONN	VOLTAGE=2.5V	PP_PMU_VDD_RTC
		VOLTAGE=1.2V	PP_PMU_VREF
		VOLTAGE=5.25V	PP_PMU_VSW_CHG
		VOLTAGE=5.7V	PP_SAGE_LX
		VOLTAGE=17V	PP_SAGE_LY
		VOLTAGE=13.5V	PP_SAGE_TO_TOUCH_VCPH
		VOLTAGE=13.5V	PP_SAGE_TO_TOUCH_VCPH_CONN
		VOLTAGE=-12V	PP_SAGE_TO_TOUCH_VCPL
		VOLTAGE=-12V	PP_SAGE_TO_TOUCH_VCPL_CONN
		VOLTAGE=18V	PP_SAGE_VBST_OUTH
		VOLTAGE=-14V	PP_SAGE_VBST_OUTL
		VOLTAGE=-12V	PP_SAGE_VCPL_F
		VOLTAGE=1.8V	PP_SPKAMP_FILT
		VOLTAGE=1V	PP_SPKAMP_LDO_FILT
		VOLTAGE=8V	PP_SPKAMP_SW
		VOLTAGE=5V	PP_STRB_DRIVER_TO_LED_COOL
		VOLTAGE=5V	PP_STRB_DRIVER_TO_LED_WARM
		VOLTAGE=4.3V	PP_VCC_MAIN
		VOLTAGE=4.3V	PP_VCC_MAIN_CODEC
		VOLTAGE=22V	PP_WLED_LX

www.vinafix.vn

RADIO_MLB HIERARCHICAL SYMBOL

AP/RADIO INTERFACE



BOARD_ID BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
118S0621	1	1.00M 1% 01005	R25_RF	Y	N51_CFG_A
118S0732	1	50K 1% 01005	R26_RF	Y	N51_CFG_A
117S0159	1	470K 5% 01005	R25_RF	Y	N51_CFG_B
118S0626	1	100K 1% 01005	R26_RF	Y	N51_CFG_B
118S0626	1	100K 1% 01005	R25_RF	Y	N53_CFG_A
118S0726	1	162K 1% 01005	R26_RF	Y	N53_CFG_A
118S0626	1	100K 1% 01005	R25_RF	Y	N53_CFG_B
118S0623	1	267K 1% 01005	R26_RF	Y	N53_CFG_B
118S0659	1	255K 1% 01005	R25_RF	Y	N48_CFG_A
118S0626	1	100K 1% 01005	R26_RF	Y	N48_CFG_A
118S0689	1	147K 1% 01005	R26_RF	Y	N48_CFG_B
118S0626	1	100K 1% 01005	R26_RF	Y	N48_CFG_B
118S0626	1	100K 1% 01005	R25_RF	Y	N49_CFG_A
118S0650	1	499K 1% 01005	R26_RF	Y	N49_CFG_A
118S0732	1	50K 1% 01005	R25_RF	Y	N49_CFG_B
118S0621	1	1.00M 1% 01005	R26_RF	Y	N49_CFG_B

www.vinafix.vn

BOARD_ID BOM OPTIONS

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
118S0621	1	1.00M 1% 01005	R25_RF	Y	N51_CFG_A
118S0732	1	50K 1% 01005	R26_RF	Y	N51_CFG_A
117S0159	1	470K 5% 01005	R25_RF	Y	N51_CFG_B
118S0626	1	100K 1% 01005	R26_RF	Y	N51_CFG_B
118S0626	1	100K 1% 01005	R25_RF	Y	N53_CFG_A
118S0726	1	162K 1% 01005	R26_RF	Y	N53_CFG_A
118S0626	1	100K 1% 01005	R25_RF	Y	N53_CFG_B
118S0623	1	267K 1% 01005	R26_RF	Y	N53_CFG_B
118S0659	1	255K 1% 01005	R25_RF	Y	N48_CFG_A
118S0626	1	100K 1% 01005	R26_RF	Y	N48_CFG_A
118S0689	1	147K 1% 01005	R26_RF	Y	N48_CFG_B
118S0626	1	100K 1% 01005	R26_RF	Y	N48_CFG_B
118S0626	1	100K 1% 01005	R25_RF	Y	N49_CFG_A
118S0650	1	499K 1% 01005	R26_RF	Y	N49_CFG_A
118S0732	1	50K 1% 01005	R25_RF	Y	N49_CFG_B
118S0621	1	1.00M 1% 01005	R26_RF	Y	N49_CFG_B

SCH :951-2770
BOM :639-3973
BOARD :820-3382

PART#	QTY	DESCRIPTION	REFERENCE DESIGNATOR(S)	CRITICAL	BOM OPTION
951-2446	1	X152_RADIO_MLB	SCH	Y	
825-2029	1	EEE FOR 939-0308	EEEE_????	Y	NA

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

AP INTERFACE & DEBUG CONNECTORS

AP CONNECTIONS

IN = FROM AP
OUT = TO AP

16 15 14 13 12 11 3 2	PP_BATT_VCC_CONN	OUT	
29	PP_VCC_MAIN_WLAN	OUT	
6	TX_GTR_THRESH	OUT	
4 2	BB_RST_L	IN	
6 2	RESET_DET_L	OUT	
4 2	RADIO_ON_L	IN	
4 2	RESET_PMU_L	IN	
6 2	HOST_WAKE_BB	OUT	
2	RF_RESET_L	OUT	
6 2	PBL_RUN_BB_HSIC1_RDY	OUT	
23 2	WLAN_HSIC3_RESUME	OUT	
6	AP_WAKE_MODEM	OUT	
6 2	AP_HSIC1_RDY	IN	
5 2	50_HSIC_BB_DATA	IO	
5 2	50_HSIC_BB_STROBE	IO	
6	BB_HSIC1_REMOTE_WAKE	OUT	
6 2	BB_UART_TXD	OUT	
6 2	BB_UART_RXD	IN	
6 2	BB_UART_RTS_L	OUT	
6 2	BB_UART_CTS_L	IN	
5 2	BB_USB_VBUS	IN	
5 2	90_BB_USB_D_P	IO	
5 2	90_BB_USB_D_N	IO	
6 2	BB_I2S_CLK	IN	
6 2	BB_I2S_WS	IN	
6 2	BB_I2S_TXD	OUT	
6 2	BB_I2S_RXD	IN	
6	PP_SYNC	OUT	
29	PP_WL_BT_VDDIO_AP	IN	
23 2	CLK32K_AP	IN	
23 2	WLAN_REG_ON	IN	
29	WLAN_UART_TXD	OUT	
29	WLAN_UART_RXD	IN	
29	HOST_WAKE_WLAN	OUT	
23 2	WLAN_HSIC3_DEVICE_RDY	OUT	
23 2	AP_HSIC3_RDY	IN	
23 2	50_HSIC_WLAN_DATA	IO	
23 2	50_HSIC_WLAN_STROBE	IO	
29	HOST_WAKE_BT	OUT	
23 2	BT_WAKE	IN	
23 2	BT_UART_TXD	OUT	
23 2	BT_UART_RXD	IN	
29	BT_UART_RTS_L	OUT	
29	BT_UART_CTS_L	IN	
23 2	BT_REG_ON	IN	
29	BT_PCM_CLK	IO	
29	BT_PCM_SYNC	IO	
29	BT_PCM_OUT	IO	
29	BT_PCM_IN	IO	
6 2	LAT_SW1_CTL	OUT	
6	LAT_SW2_CTL	OUT	
6	LAT_SW3_CTL	OUT	
20 6	BB_SPI_TO_PAC_CS	OUT	
20 6	BB_SPI_TO_PAC_DATA_MOSI	OUT	
20 6	BB_SPI_TO_PAC_CLK	OUT	
20 6	PAC_TO_BB_SPI_DATA_MISO	IN	
20 18 17 11 10 3	PP_LDO14_2V65	OUT	
5 2	BB_JTAG_TCK	IN	
5 2	BB_JTAG_TDI	IN	
5 2	BB_JTAG_TMS	IN	
5 2	BB_JTAG_TRST_L	IN	
5 2	BB_JTAG_TDO	OUT	
2	ADC_SMPS1_MSMC_1V05	OUT	
2	ADC_SMPS3_MSME_1V8	OUT	
2	ADC_LDO6_RUIM_1V8	OUT	
2	ADC_LVS1	OUT	
6	BB_IPC_GPIO	OUT	
23 6	OSCAR_CONTEXT_A	IN	
23 6	OSCAR_CONTEXT_B	IN	

PROBE POINTS

PP1_RF — P4MM SM — 1 BB_ERROR_FLAG — 6
PP2_RF — P4MM SM — 1 SLEEP_CLK_32K — 4 5
PP3_RF — P4MM SM — 1 PMIC_SSBI — 4 5
PP11_RF — P4MM SM — 1 CLK32K_AP — 2 23
PP14_RF — P4MM SM — 1 AP_HSIC3_RDY — 2 23
PP15_RF — P4MM SM — 1 WLAN_HSIC3_DEVICE_RDY — 2 23
PP18_RF — P4MM SM — 1 WLAN_HSIC3_RESUME — 2 23
PP19_RF — P4MM SM — 1 WTR_SSBI_TX_GPS — 6 7
PP20_RF — P4MM SM — 1 WTR_SSBI_PRX_DRX — 6 7
PP21_RF — P4MM SM — 1 WTR_RX_ON — 6 7
PP22_RF — P4MM SM — 1 WTR_RF_ON — 6 7
PP40_RF — P4MM SM — 1 WLAN_COEX_TXD — 23
PP41_RF — P4MM SM — 1 LTE_COEX_TXD — 6 23
PP42_RF — P4MM-NSM SM — 1 50_HSIC_BB_STROBE — 2 5
PP43_RF — P4MM-NSM SM — 1 50_HSIC_BB_DATA — 2 5
PP44_RF — P4MM SM — 1 50_HSIC_WLAN_STROBE — 2 23
PP45_RF — P4MM SM — 1 50_HSIC_WLAN_DATA — 2 23
PP46_RF — P4MM SM — 1 BT_UART_TXD — 2 23
PP47_RF — P4MM SM — 1 BT_UART_RXD — 2 23
PP4_RF — P4MM SM — 1 BB_I2S_CLK — 2 6
PP5_RF — P4MM SM — 1 BB_I2S_WS — 2 6
PP6_RF — P4MM SM — 1 BB_I2S_RXD — 2 6
PP7_RF — P4MM SM — 1 BB_I2S_TXD — 2 6
PP8_RF — P4MM-NSM SM — 1 SIMCRD_RST_CONN — 2 6
PP9_RF — P4MM-NSM SM — 1 SIMCRD_CLK_CONN — 2 6
PP10_RF — P4MM SM — 1 SPI_DATA_MOSI — 6
PP12_RF — P4MM SM — 1 SPI_CLK — 6
PP13_RF — P4MM SM — 1 SPI_CS_L — 6
PP16_RF — P4MM SM — 1 SPI_DATA_MISO — 6

DEBUG CONNECTOR

J1_RF
AXE654124
M-ST-SM

5	OUT	DEBUG_RST_L	10	9	PP_SMPS3_MSME_1V8 — IN 2 3 5 6 8
4 2	OUT	RESET_PMU_L	12	11	BT_WAKE — OUT 2 23
4 2	OUT	RADIO_ON_L	14	13	
			16	15	PP_LDO6_RUIM_1V8 — IN 2 3 5
5 2	OUT	BB_USB_VBUS	18	17	WLAN_REG_ON — OUT 2 23
5 2	BI	90_BB_USB_D_N	20	19	NC
5 2	BI	90_BB_USB_D_P	22	21	NC
2	OUT	RF_RESET_L	24	23	PMIC_RESOUT_L — IN 4 5
5 2	OUT	BB_JTAG_TCK	26	25	NC
5 2	OUT	BB_JTAG_TMS	28	27	
5 2	IN	BB_JTAG_TDO	30	29	AP_HSIC1_RDY — IN 2 6
5 2	OUT	BB_JTAG_TDI	32	31	BT_REG_ON — IN 2 23
5 2	OUT	BB_JTAG_TRST_L	34	33	HOST_WAKE_BB — IN 2 6
5	OUT	BB_JTAG_RTCLK	36	35	NC
			38	37	RESET_DET_L — IN 2 6
4	OUT	PS_HOLD_PMIC	40	39	SIMCRD_CLK_CONN — IN 2 6
6 2	IN	BB_UART_TXD	42	41	SIMCRD_IO_CONN — BI 2 6
6 2	OUT	BB_UART_RXD	44	43	SIM_TRAY_DETECT — OUT 2 6
6 2	IN	BB_UART_RTS_L	46	45	BB_RST_L — OUT 2 4
6 2	OUT	BB_UART_CTS_L	48	47	SIMCRD_RST_CONN — IN 2 6
6	IN	GPIO_DEBUG_LED	50	49	PBL_RUN_BB_HSIC1_RDY — IN 2 6
6	OUT	GPIO_51	52	51 GPIO54/BOOT_CONFIG_0	ANT_SEL_2 — OUT 6 17 18
18 17 11 6	OUT	ANT_SEL_1	54	53 GPIO48/BOOT_CONFIG_6	LAT_SW1_CTL — OUT 2 6
			58	57	

PP_BATT_VCC_CONN — IN 2 3 11 12 13 14 15 16
GPIO51/BOOT_CONFIG_3
GPIO53/BOOT_CONFIG_1

BOOT OPTIONS	BOOT_CONFIG SW REGISTER VALUE	GPIO/BOOT_CONFIG CONFIGURATION							
		6	5	4	3	2	1	0	
		47	48	49	50	51	52	53	54	55
BOOT_DEFAULT_OPTION	0X00	X	0	0	0	0	0	0	X
BOOT_NAND_OPTION	0X01	X	1	0	0	0	0	1	X
BOOT_HSIC_OPTION	0X02	X	1	0	0	0	1	0	X
BOOT_USB_OPTION	0X03	X	1	0	0	0	1	1	X
ENABLE SAHARA PROTOCOL	0X08	X	1	0	0	1	0	X	X

J2_RF
MM4829-2702
F-ST-SM
NOSTUFF — 1 50_HSIC_BB_DATA — 2 5

J3_RF
MM4829-2702
F-ST-SM
NOSTUFF — 1 50_HSIC_BB_STROBE — 2 5

SIM CARD CONNECTOR

PP_LDO6_RUIM_1V8 — 5 3 2
R3_RF 15.00K 1% 1/32W MF 01005
J11_RF SIM-CARD-N48 F-ST-SM
VCC 1
RST 2 — 6 2 IN SIMCRD_RST_CONN
CLK 3 — 6 2 IN SIMCRD_CLK_CONN
I/O 7 — SIMCRD_IO_CONN — BI 2 6
DETECT 12 — SIM_TRAY_DETECT — OUT 2 6
SWP 6
GND 8 9 10 11 13 5
C700_RF 100PF 5% 16V NP0-C0G 01005

SIM CARD ESD PROTECTION

PP_LDO6_RUIM_1V8 — 2 3 5
C1_RF 12V-33PF 01005
U5_RF TPD4E101DPWR SON4
1 SIMCRD_IO_CONN — 6 2
2 SIMCRD_RST_CONN — 6 2
3 SIMCRD_CLK_CONN — 2 6
4 SIM_TRAY_DETECT — 2 6
5 GND

XW12_RF / XW13_RF / XW14_RF / XW15_RF

SHORT-10L-0.1MM-SM
PP_SMPS1_MSMC_1V05 — 5 3 — ADC_SMPS1_MSMC_1V05 — 2
PP_SMPS3_MSME_1V8 — 8 6 5 3 2 — ADC_SMPS3_MSME_1V8 — 2
PP_LDO6_RUIM_1V8 — 5 3 2 — ADC_LDO6_RUIM_1V8 — 2
PP_LVS1 — 5 3 — ADC_LVS1 — 2

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

PMU (1 OF 2)



CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

PMU (2 OF 2)

PA_ID	CONFIG
1.1V	CONFIG A
1.3V	CONFIG B
1.5V	CONFIG C
1.7V	CONFIG D

BOARD_ID	REVISION
0.7V	PROTO1
0.9V	PROTO2
1.1V	EVT1
1.3V	EVT2
1.5V	DVT
1.7V	PVT



AP SECTION NEEDS ITS OWN THERMISTOR PLACED NEAR THE PA'S.







CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

BASEBAND (1 OF 2)











CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

BASEBAND (2 OF 2)





CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

RF TRANSCEIVER (1 OF 2)

PRX TRANSCEIVER RF AND IQ PORTS



DRX TRANSCEIVER RF AND IQ PORTS



TRANSCEIVER GROUND CONNECTIONS



TRANSCEIVER PHASE CONTROL, TX RF & IQ PORTS



CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

RF TRANSCEIVER (2 OF 2)

RF1_1V3

R53_RF
0
5%
1/20W
MF
201

PP_SMPS2_RF1_1V3
PP_SMPS2_RF1_1V3_FILT

C72_RF
10UF
20%
10V
X5R-CERM
0402-1

STAR ROUTING

PP_RF1_1V3_PRX_PLL	C73_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.66
PP_RF1_1V3_SHDR_PLL	C74_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.65
PP_RF1_1V3_PRX_VCO	C75_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.76
PP_RF1_1V3_SHDR_VCO	C76_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.40
PP_RF1_1V3_TX_DA	C77_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.118 NOSTUFF
	C274_RF	56PF 5% 16V NP0-C0G 01005
PP_RF1_1V3_TX_SYNTH	C78_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.98
PP_RF1_1V3_TX_LO	C79_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.116
PP_RF1_1V3_TX_UPCONVERTER	C80_RF	100PF 5% 16V NP0-C0G 01005 PLACE NEAR U3.117
PP_RF1_1V3_PRX_FELO1	C81_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.53 AND U3.26
PP_RF1_1V3_DRX_FE		
PP_RF1_1V3_PRX_FELO2	C82_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.42
PP_RF1_1V3_DRX_LBLO	C83_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.25 AND U3.28
PP_RF1_1V3_DRX_MBLO		
PP_RF1_1V3_JAM_DET		

RF1_1V3

PP_SMPS2_RF1_1V3_FILT

PP_RF1_1V3_GPS_LNA	C85_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.24 AND U3.31
PP_RF1_1V3_GPS_DIG		
PP_RF1_1V3_GPS_VCO	C86_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.37 AND U3.55
PP_RF1_1V3_GPS_PLL		

RF1_1V8

PP_SMPS3_MSME_1V8

C87_RF
1.0UF
20%
10V
X5R-CERM
0201-1
PLACE NEAR U3.87

PP_RF1_1V8_DIG

RF2_2V05

R19_RF
0
5%
1/20W
MF
201

PP_SMPS4_RF2_2V05
PP_SMPS4_RF2_2V05_FILT

C88_RF
10UF
20%
10V
X5R-CERM
0402-1

STAR ROUTING

PP_RF2_2V05_DRX_BB		
PP_RF2_2V05_TX_DA	C244_RF	100PF 5% 16V NP0-C0G 01005 PLACE NEAR U3.111
PP_RF2_2V05_PRX_BB		
PP_RF2_2V05_TX_BB		
PP_RF2_2V05_PRX_VCO	C89_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.67
PP_RF2_2V05_SHDR_VCO	C90_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.51
PP_RF2_2V05_TX_VCO	C91_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.136
PP_RF2_2V05_TX_PLL		
PP_RF2_2V05_XO_FILT	C92_RF	0.1UF 20% 6.3V X5R-CERM 01005 PLACE NEAR U3.127

TRANSCEIVER POWER CONNECTIONS

U3_RF
WTR1605
SM
SRM 4 OF 5
PWR

PP_RF1_1V3_PRX_FELO1	53	VDD_RF1_P_FELO	VDD_RF2_T_DA	111	PP_RF2_2V05_TX_DA
PP_RF1_1V3_PRX_FELO2	42	VDD_RF1_P_FELO	VDD_RF1_T_DA	118	PP_RF1_1V3_TX_DA
PP_RF1_1V3_DRX_LBLO	28	VDD_RF1_D_LBLO	VDD_RF1_T_UPC	117	PP_RF1_1V3_TX_UPCONVERTER
PP_RF1_1V3_DRX_FE	26	VDD_RF1_D_FE	VDD_RF1_T_LO	116	PP_RF1_1V3_TX_LO
PP_RF1_1V3_DRX_MBLO	25	VDD_RF1_D_MBLO	VDD_RF2_T_BB	108	PP_RF2_2V05_TX_BB
PP_RF1_1V3_JAM_DET	85	VDD_RF1_JDET	VDD_RF2_T_VCO	136	PP_RF2_2V05_TX_VCO
PP_RF2_2V05_PRX_BB	83	VDD_RF2_P_BB	VDD_RF2_XO	127	PP_RF2_2V05_XO_FILT
PP_RF2_2V05_DRX_BB	44	VDD_RF2_D_BB	VDD_RF1_T_SYN	98	PP_RF1_1V3_TX_SYNTH
PP_RF2_2V05_PRX_VCO	67	VDD_RF2_P_VCO	VDD_RF2_T_PLL	97	PP_RF2_2V05_TX_PLL
PP_RF1_1V3_PRX_VCO	76	VDD_RF1_P_VCO			
PP_RF1_1V3_PRX_PLL	66	VDD_RF1_P_PLL	VDD_RF1_G_LNA	24	PP_RF1_1V3_GPS_LNA
PP_RF2_2V05_SHDR_VCO	51	VDD_RF2_S_VCO	VDD_RF1_G_VCO	37	PP_RF1_1V3_GPS_VCO
PP_RF1_1V3_SHDR_VCO	40	VDD_RF1_S_VCO	VDD_RF1_G_PLL	55	PP_RF1_1V3_GPS_PLL
PP_RF1_1V3_SHDR_PLL	65	VDD_RF1_S_PLL	VDD_RF1_G_BB	31	PP_RF1_1V3_GPS_DIG
			VDD_DIO	87	PP_RF1_1V8_DIG

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

RX MATCHING













www.vinafix.vn

TX INTERSTAGE FILTERS







CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

BAND 1/34/39/38/40 TX



BAND	PA POWER MODE	PA_BS	PA_CTL1	PA_CTL0	PA_R1
OFF	X	X	0	0	0
B1	HPM	X	1	0	0
B1	LPM	X	1	0	1
B34	HPM	1	0	1	0
B34	LPM	1	0	1	1
B39	HPM	0	0	1	0
B39	LPM	0	0	1	1
B38	HPM	1	1	1	0
B38	LPM	1	1	1	1
B40	HPM	0	1	1	0
B40	LPM	0	1	1	1

www.vinafix.vn

BAND 2/3 PAD



BAND	PA_POWER_MODE	PA_BS	PA_ON_B2_B3	PA_R1
OFF	X	X	0	X
B3	HPM	0	1	0
B3	LPM	0	1	1
B2	HPM	1	1	0
B2	LPM	1	1	1

www.vinafix.vn

BAND 20/7 PAD



BAND	PA_POWER_MODE	PA_BS	PA_ON_B20_B7	PA_R1
OFF	X	X	0	X
B20	HPM	0	1	0
B20	LPM	0	1	1
B7	HPM	1	1	0
B7	LPM	1	1	1

www.vinafix.vn

BAND 5/8 PAD



BAND	PA POWER MODE	PA_BS	PA_ON_B5_B8	PA_R1
OFF	X	X	0	X
B5	HPM	0	1	0
B5	LPM	0	1	1
B8	HPM	1	1	0
B8	LPM	1	1	1

www.vinafix.vn

2G PA

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSES ONLY - NOT A CHANGE REQUEST.

2G PA GAIN MODES

BAND	MODE	GAIN MODE	PA_R1	PCL RANGE
LOW BAND	GSM	ULTRA LOW	HIGH	16 TO 19
LOW BAND	GSM	LOW	HIGH	14 TO 15
LOW BAND	GSM	MEDIUM	LOW	7 TO 13
LOW BAND	GSM	HIGH	LOW	5 TO 6
HIGH BAND	GSM	ULTRA LOW	HIGH	10 TO 15
HIGH BAND	GSM	LOW	HIGH	7 TO 9
HIGH BAND	GSM	HIGH	LOW	0 TO 6
LOW BAND	EDGE	LOW	HIGH	15 TO 19
LOW BAND	EDGE	MEDIUM	LOW	10 TO 14
LOW BAND	EDGE	HIGH	LOW	8 TO 9
HIGH BAND	EDGE	LOW	HIGH	9 TO 15
HIGH BAND	EDGE	HIGH	LOW	2 TO 8



www.vinafix.vn

PA DC/DC CONVERTER



CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

PRIMARY ASM



CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

RX DIVERSITY



CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

GPS



www.vinafix.vn

ANTENNA FEEDS

UAT1

SP1_RF
1.6X1.21MM
SM-NSP
50_UPPER_ANT_FEED

FL1701_RF
FLTR-GPS-0603
LFE18832MHC1D449
NC

L1732_RF
2.4NH+/-0.2NH-0.57A-0.07OHM
03015
50_NTCH_FLT_OUT
50_UPPER_MCH_1

C1726_RF
0.8PF
+/-0.1PF
16V
NP0-C0G
01005

L6_RF
5.6NH-3%-140MA
01005
PAC_TO_BB_SPI_DATA_MISO
PAC_TO_BB_SPI_DATA_MISO_FILT

L66_RF
5.6NH-3%-140MA
01005
BB_SPI_TO_PAC_CS
BB_SPI_TO_PAC_CS_FILT

L67_RF
5.6NH-3%-140MA
01005
BB_SPI_TO_PAC_DATA_MOSI
BB_SPI_TO_PAC_DATA_MOSI_FILT

L68_RF
5.6NH-3%-140MA
01005
BB_SPI_TO_PAC_CLK
BB_SPI_TO_PAC_CLK_FILT

C96_RF 56PF 5% 16V NP0-C0G 01005
C97_RF 56PF 5% 16V NP0-C0G 01005
C98_RF 56PF 5% 16V NP0-C0G 01005
C38_RF 56PF 5% 16V NP0-C0G 01005

U7_RF
RF1112
WLCSP
MISO
RF1
CS
MOSI
SCLK
VDD
RF2
NC
GND

L69_RF
5.6NH-3%-140MA
01005
PP_LDO14_PAC_2V65

C247_RF 56PF 5% 16V NP0-C0G 01005
C99_RF 0.01UF 10% 6.3V X5R 01005

TP1_RF
TP-P6
50_UAT_CELL

L8_RF
6.2NH-390MA
03015

U18_RF
0.3-2170MHZ
LLP
IN/OUT
OUT/IN
GND
50_UAT1_LPF

L48_RF
1.7NH+/-0.1NH-0.60A
0201
50_WLAN_G
50_EXTRACTOR_WIFI

U9_RF
885041
DIPLEXER-CELL-WIFI
LGA
ANT
SMD2_ANT/
SMD4_GND
SMD3/WLAN
RF2/CELL_SMD1
SMD1
GND

L51_RF
4.7NH-3%-0.35A
0201
50_EXTRACTOR_CELL
50_B7_B38_B40_SPDT

C271_RF 56PF 5% 16V NP0-C0G 01005
C157_RF 0.01UF 10% 6.3V X5R 01005
PP_LDO14_2V65

UAT1 COAX

U13_RF
CXA4011GC
XFLGA
VDD
RF1
RF2
VC1
GND
50_UAT_COAX_DOWN
50_UAT_COAX_UP

J6_RF
MM5829-2700
F-ST-SM

J5_RF
MM5829-2700
F-ST-SM

BS_SP2T_CTL

C158_RF
56PF
5%
16V
NP0-C0G
01005

UAT2

DPX165950DT-8030C1
U12_RF
SM
LOW_BAND
HIGH_BAND
COMMON
GND
50_UAT2_DIPLEX
50_WLAN_A

L50_RF
3.4NH-3%-0.45A
0201
50_EXTRACTOR_DIPLEX_1

L49_RF
5.6NH-3%-140MA
01005

J10_RF
MM5829-2700
F-ST-SM
50_UAT2_ANT_FD

C101_RF
0.2PF
+/-0.1PF
25V
C0G-CERM
201
NOSTUFF

R13_RF
0
5%
1/20W
MF
201
250_UAT2_ANT_MATCH

LAT

J4_RF
MM5829-2700
F-ST-SM
50_LAT_COAX

R11_RF
3.0NH+/-0.1NH-0.45A
0201
50_LAT_MATCH

C94_RF
1.0PF
+/-0.1PF
25V
NP0-C0G
201
NOSTUFF

C95_RF
1.0PF
+/-0.1PF
25V
NP0-C0G
201
NOSTUFF

J9_RF
MM8930-2600B
F-RT-SM
GND
50_LAT_TEST

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn

WLAN/BT



PULL-UP ON GPIO6, SDIO_DATA_2 & PULL-DOWN ON SDIO_DATA_1 REQUIRED FOR HSIC BOOTSTRAPPING

CONFIDENTIAL AND PROPRIETARY APPLE SYSTEM DESIGN. FOR REFERENCE PURPOSE ONLY - NOT A CHANGE REQUEST

www.vinafix.vn